


Digital PID Temperature Controllers

Model: WT404/904/707/409/909

Ver 1.3

Operation Manual



Preface

Thank you for purchasing the Shihlin Electric WT series digital temperature controllers.

This User's Manual contains instructions for mounting, functions, operations and notes when operating the WT series digital temperature controllers.

To prevent accidents arising from the misuse of this controller, please ensure the operator receives this manual.

Notes

- This instrument should be used in accordance with the specifications described in the manual.
If it is not used according to the specifications, it may malfunction or cause a fire.
- Be sure to follow the warnings, cautions and notices. If they are not observed, serious injury or malfunction may occur.
- The contents of this instruction manual are subject to change without notice.
- Care has been taken to ensure that the contents of this instruction manual are correct, but if there are any doubts, mistakes or questions, please inform our company.
- Measures must be taken to ensure that the operator cannot touch power terminals or other high voltage sections.
- Any unauthorized transfer or copying of this document, in part or in whole, is prohibited.
- Shihlin Electric is not liable for any damage or secondary damage(s) incurred as a result of using this product, including any indirect damage.

Copyright and Trademark

Shihlin Electric owns the copyright of this manual.

- Reproduction of this manual without express permission from Shihlin Electric is prohibited.
- Modbus protocol is a communication protocol that Modicon Inc. Developed for PLC and Modbus is a registered trademark of Schneider Electric.
- Other company names and the product names are the trademarks or registered trademarks of each company.



WARNING : This mark indicates precautions that must be taken if there is danger of electric shock, fire, etc., which could result in loss of life or injury.



CAUTION : This mark indicates that if these precautions and operating procedures are not taken, damage to the instrument may result.


WARNING

- An external protection device must be installed if failure of this instrument could result in damage to the instrument, equipment or injury to personnel.
- All wiring must be completed before power is turned on to prevent electric shock, fire or damage to instrument and equipment.
- This instrument must be used in accordance with the specifications to prevent fire or damage to instrument and equipment.
- This instrument is not intended for use in locations subject to flammable or explosive gases.
- Do not touch high-voltage connections such as power supply terminals, etc. to avoid electric shock.
- Shihlin Electric is not responsible if this instrument is repaired, modified or disassembled by other than factory-approved personnel.

Malfunction can occur and warranty is void under these conditions.

⚠ CAUTION

- This product is intended for use with industrial machines, test and measuring equipment. It is not designed for use with medical equipment and nuclear energy.
- This is a Class A instrument. In a domestic environment, this instrument may cause radio interference, in which case the user may be required to take additional measures.
- This instrument is protected from electric shock by reinforced insulation.
Provide reinforced insulation between the wire for the input signal and the wires for instrument power supply, source of power and loads.
- This instrument is designed for installation in an enclosed instrumentation panel. All high-voltage connections such as power supply terminals must be enclosed in the instrumentation panel to avoid electric shock by operating personnel.
- All precautions described in this manual should be taken to avoid damage to the instrument or equipment.
- All wiring must be completed before power is turned on to prevent electric shock, instrument failure, or incorrect action.
- The power must be turned off before repairing work for input break and output failure including replacement of sensor, contactor or SSR, and all wiring must be completed before power is turned on again.
- Prevent metal fragments or lead wire scraps from falling inside instrument case to avoid electric shock, fire or malfunction.
- Please use crimp terminals suitable for M3 screws, as shown below:



- Tighten each terminal screw to the specified torque found in the manual to avoid electric shock, fire or malfunction.
- When the thermocouple wiring is extended, please use the compensation lead of the corresponding type to this thermocouple.

Content

1.	Order Information	7
2.	Specifications	8
3.	Input Range Table.....	9
4.	Packing List & Label Information	9
4.1	Packing List Guide	9
4.2	Label Guide	10
4.2.1	WT404	10
4.2.2	WT707	10
4.2.3	WT904/409/909	11
5.	Parts Description.....	12
6.	Installation.....	13
6.1	WT404 Dimensions	13
6.2	WT904 Dimensions	13
6.3	WT707 Dimensions	13
6.4	WT409 Dimensions	14
6.5	WT909 Dimensions	14
7.	Terminal Arrangement	15
7.1	WT404 Terminal Arrangement	15
7.2	WT904 Terminal Arrangement	16
7.3	WT707 Terminal Arrangement	17
7.4	WT409 Terminal Arrangement	18
7.5	WT909 Terminal Arrangement	19
8.	Basic Function Setting.....	20
8.1	Change Input Type	20
8.2	SV Setting	20
8.3	RUN/STOP Mode Selection.....	20
8.4	Setting PID Value Automatically(Auto-tunning)	20
8.5	Setting PID Value Manually	21
8.6	Controlling With ON/OFF Action	21
8.7	Alarm Mode Setting	21
8.8	Alarm Value Setting	22
8.9	Controlling With Manual Control	22
9.	Flow Chart Of Parameter Setting.....	23
9.1	Parameter Structure	23
9.2	Level Operation Mode	24
9.3	Level Operation Diagram.....	24
9.4	Data Lock Function.....	25
9.5	Level 1 (User Level) All Parameters Display	25
9.6	LEVEL_1 Parameter.....	26
9.7	Level 2 (PID Level) All Parameters Display.....	28
9.8	LEVEL_2 Parameter.....	29
9.9	Level 3 (Input Level) All Parameters Display.....	31

9.10	LEVEL_3 Parameter	32
9.11	Level 4 (Setting Level) All Parameters Display	34
9.12	LEVEL_4 Parameter	35
9.13	Level 5 (Quality Control) All Parameters Display	37
9.14	LEVEL_5 Parameter	38
9.15	Fast Parameter Access	41
9.16	Fast Level Parameter	42
10.	Parameters Hide/Display Table On Level 4	44
11.	Functional Descriptions	46
11.1	Input Calibration	46
11.2	Retransmission	47
11.3	Remote SV	49
11.4	Heater Break Alarm	51
11.5	A/M Key	53
11.6	Digital Input	55
11.7	Dehumidification Function	59
11.8	24-Hour Timer	60
11.9	Motor Valve Control	62
11.10	Piece Linear Compensation	65
11.11	RAMP & SOAK	68
11.12	Password	71
11.13	Proportional Control	72
11.14	Master-Slave Communication	73
12.	Alarm Action	74
12.1	Alarm Mode	76
12.2	Alarm Special Setting	79
12.3	Alarm Example	80
13.	Programmable	81
13.1	Parameter Setting	81
13.2	Key Operation Description	82
13.3	Program Initial Setting	82
13.4	Create Program	84
13.5	Program Execution Flow	86
13.6	Program Setting Example	86
14.	Modification Of Output Module	87
14.1	Relay Control (1a)	87
14.2	Relay Control (1c)	87
14.3	SSR Control	87
14.4	Linear Control	87
14.5	Output Calibration Procedure Diagram	88
14.6	Output Calibration Steps	89
15.	Modification Of Input Signal	90
15.1	Input Modify To Thermocouple	90

15.2	Input Modify To RTD.....	90
15.3	Input Modify To Linear (4~20mA)	91
15.4	Steps For Input Calibration	92
16.	Zero / Phase Control	93
16.1	1φ Zero Cross Control (SCR module)	93
16.2	1φ Zero Cross Control (TRIAC module).....	93
16.3	3φ Zero Cross Control (SCR module)	94
16.4	3φ Zero Cross Control (TRIAC module).....	94
16.5	1φ Phase Angle Control (SCR module).....	95
16.6	1φ Phase Angle Control (TRIAC module).....	95
17.	Error Message.....	96
18.	WT Communication Register Address Table.....	96
19.	FY Communication Register Address Table.....	98
20.	Program Design Table	99
21.	Glossary Of Characters Used In This Manual.....	101
22.	WT Parameter Abbreviation Descriptions	102

1. Order Information

Model	Output 1	Output 2	Alarm	TRS	Remote	COMM	Input type	Power	Accessories
WT404	1 0	0 None	1 0	0 None	0 None	0 None	0 See input Range type code	A AC 85~265V	N None
WT904	1 Relay	1 Relay	1 1 Set	1 0	4~20mA	1 4~20mA	3 TTL	D DC 24V	A Standard
WT707	2 Voltage Pulse (SSR Drive)	2 Voltage Pulse (SSR Drive)	2 2 Sets	2 0~20mA	2 0~20mA	B RS-485(FY)			
WT409	3 4~20mA	3 4~20mA	3 3 Sets	A 0~5V	A 0~5V	C RS-485(WT)			B Programmable
WT909	4 0~20mA	4 0~20mA		B 0~10V	B 0~10V				
	A 0~5V	A 0~5V		C 1~5V	C 1~5V				
	B 0~10V	B 0~10V		D HBA	D 2~10V				
	C 1~5V	C 1~5V		B HBA+AL2		E DI			
	D 2~10V	D 2~10V		C HBA+AL2+AL3		F Remote + DI			
	5 1φSCR zero cross control					M Motor valve control feedback	※  Block means optional functions with additional charge		
	6 3φSCR zero cross control					J PT(Second Input)	※ HBA : Heater Break Alarm(HBA must use AL1 as alarm relay)		
	7 Motor valve control					K TC(Second Input)	※ The Second Input FY600/800/900 only		
	8 1φSCR phase angle control					L Linear(Second Input)			

※  Boxed-in items are optional functions, which shall incur extra charges

2. Specifications

Model	WT404	WT904	WT707	WT409	WT909
Supply Voltage	AC 85 ~ 265V, DC 24V (Optional Functions)				
Power Frequency	50/60 Hz				
Power Consumption	Approximately 6VA				
Memory	Non-Volatile Memory EEPROM				
Sensor Input ※ Please refer to Input Range Table	Cold junction compensation diode external Accuracy : 0.1%				
	Cold junction compensation diode internal Accuracy : 0.3%				
	Sample time : 50ms				
	Thermocouple : (K, J, R, S, B, E, N, T, W, PL II, L)				
	RTD: PT100				
Output	DC Linear Analog Input: 0~20mA, 4~20mA 0~1V, 0~5V, 0~10V, 0~2V, 1~5V, 2~10V 0~25mV, 0~50mV, 0~70mV				
	1a	1c	1c	1c	1c
	1a SPST-NO, 250 VAC, 5A (resistive load), electrical life: 100,000 operations				
	1c SPDT-NO, 250 VAC, 5A (resistive load), electrical life: 50,000operations				
	SPDT-NC, 250 VAC, 2A (resistive load), electrical life: 20,000 operations				
OUT2 Relay	SPST-NO, 250 VAC, 5A (resistive load), electrical life: 100,000 operations				
SSR Driver	ON: 24 V OFF: 0V max. load current: 20mA, with short circuit protection circuit				
linear	4~20mA, 0~20mA, 0~5V, 0~10V, 1~5V, 2~10V				
Control Method	ON-OFF or P, PI, PID control				
Alarm	1a	1c	1a	1c	1c
	1a SPST-NO, 250 VAC, 5A(resistive load), electrical life: 100,000 operations				
	1c SPDT-NO, 250 VAC, 5A (resistive load), electrical life: 50,000operations				
	SPDT-NC, 250 VAC, 2A (resistive load), electrical life: 20,000 operations				
	---	1a	1a	1a	1a
TRS	Re-transmitted Signal	4~20mA, 0~20mA, 0~5V, 0~10V, 1~5V, 2~10V			
	Source of Re-transmission	SV1, PV1, MV1, SV1R, PV1R, MV1R, SV2, PV2, MV2, SV2R, PV2R, MV2R			
	Accuracy	0.1%			
	Resolution	14bit			
Remote SV	Signal	4~20mA, 0~20mA, 0~5V, 0~10V, 1~5V, 2~10V			
	Resolution	18 bit			
	Controlled by	SV			
Digital Input	2 points				
Communication	Interface	RS-485 Half duplex Communication MAX. 31 units, MAX. distance 1200 meters			
	Protocol	Modbus RTU, Shihlin Electric			
	Parity bit	NONE, ODD, Even			
	Data bit	8 bit			
	Stop bit	1 or 2 bit			
	Baud rate	2400,4800,9600,19200,38400,57600,115200 bps			
	Interval time	0~250ms			
Malfuction vibration	10~55 Hz 20m / s ² , for 10 min each in X, Y and Z directions.				
Vibration resistance	10~55 Hz 20m / s ² , for 2 hr each in X, Y and Z directions.				
Malfunction shock	100m / s ² , 3 times each in X, Y and Z directions.				
Shock resistance	300m / s ² , 3 times each in X, Y and Z directions.				
Operating Environment Temperature/Humidity	0 ~ 50°C (in the case of no freezing or condensatioin) / 20% ~ 90% RH				
Storage Environment Temperature	-25 ~ 65°C (in the case of no freezing or condensatioin)				
Dimension (mm)	W48 x H48 x D95	W96 x H48 x D95	W72 x H72 x D95	W48 x H96 x D95	W96 x H96 x D95
Weight	Appox.120g	Appox.170g	Appox.150g	Appox.170g	Appox.230g

3. Input Range Table

Types of input			Code	°C	Range	°F
Thermocouple	K	K1	01	-50.0~600.0	-58.0~999.9	
		K2	02	-50~1200	-58~2192	
	J	J1	03	-50.0~400.0	-58.0~752.0	
		J2	04	-50~1200	-58~2192	
	R	R	05	-50~1760	-58~3200	
	S	S	06	-50~1760	-58~3200	
	B	B	07	-50~1820	-58~3308	
	E	E	08	-50~900	-58~1652	
	N	N	09	-50~1300	-58~2372	
	T	T1	10	-199.9~400.0	-199.9~752.0	
		T2	11	-199~400	-326~752	
	W	W	12	-50~2320	-58~4208	
	PL	PL	13	-50~1200	-58~2192	
	L	L	14	-50~800	-58~1472	
RTD	PT100	PT1	15	-199.9~850.0	-199.9~999.9	
		PT2	16	-199~850	-326~1562	
		PT3	17	0~850	32~1562	
Linear	AN2	AN1	18			
		0~50mV	19			
		0~20mA	20			
		0~1V	21			
		0~2V	22			
		0~5V	23			
		0~10V	24			
	AN4	AN3	25			
		0~70mV				
		4~20mA	26			
		10~50mV	27			
		1~5V	28			
		2~10V	29			

4. Packing List & Label Information


4.1 Packing List Guide

WT404/904/707/409/909

- 1. Temperature Controller...1 unit
- 2. Mounting frame2 units
- 3. Brief manual..... 1 pcs

4.2 Label Guide


4.2.1 WT404



LN:1


No.	Item	Description
(1)	Terminal arrangement	WT404 Terminal Wiring Diagram
(2)	Model number	WT404 model name
(3)	Serial number	SP20021140001
(4)	Input type	Controller Input Signal and Range

4.2.2 WT707




No.	Item	Description
(1)	Terminal arrangement	WT707 Terminal Wiring Diagram
(2)	Model number	WT707 model name
(3)	Serial number	SP20021170001
(4)	Input type	Controller Input Signal and Range

4.2.3 WT904/409/909



No.	Item	Description
(1)	Terminal arrangement	WT909 Terminal Wiring Diagram
(2)	Model number	WT909 model name
(3)	Serial number	SP20021190001
(4)	Input type	Controller Input Signal and Range

5. Parts Description






1	PV	Indicating PV (measured value) and character information such as parameter codes or error codes(Red)	
2	SV	Indicating SV (target set value) or parameter values(Green)	
3	OUT1	Lamp lit when OUT1 is activated (Green)	
	OUT2	Lamp lit when OUT2 is activated (Green)	
	AT	Lamp lit when Auto tuning is activated (Orange)	
	AL1	Lamp lit when Alarm 1 is activated (Red)	
	AL2	Lamp lit when Alarm 2 is activated (Red)	
	AL3	Lamp lit when Alarm 3 is activated (Red)	
	MAN	Lamp lit when controller in manual mode or get error condition (Orange)	
	PRO	When the program is executed, this light is on (orange)	
4	OUT1%	Output% bar-graph indicator(Green)	
		SET	For parameter call-up and set value registration
		A/M	Function activation
		SHIFT	Shift digits when changing settings
		DOWN	Decrease numerals
		UP	Increase numerals

((6. Installation




6.1 WT404 Dimensions

(Unit : mm)

Dimensions	Individual mounting
 	 <p>Mounting fixture t (panel thickness) 1~t~6</p>




6.2 WT904 Dimensions

(Unit : mm)

Dimensions	Individual mounting
 	 <p>Mounting fixture t (panel thickness) 1~t~6</p>

6.3 WT707 Dimensions

(Unit : mm)

Dimensions	Individual mounting
 	 <p>Mounting fixture t (panel thickness) 1~t~6</p>

6.4 WT409 Dimensions

(Unit : mm)

Dimensions	Individual mounting
<p>The front panel dimensions are 50.0 mm wide by 96.0 mm high. The display area is 40.0 mm wide by 96.0 mm high. The keypad area is 14.1 mm wide by 96.0 mm high. The bottom section is 14.1 mm wide by 1.0 mm high.</p>	<p>The mounting fixture dimensions are 81.3 mm wide by 90.1 mm high. The fixture has a thickness of 1.0 mm. The mounting fixture height is 121.0 mm. The panel thickness is t (1~t~6 mm).</p>

6.5 WT909 Dimensions

(Unit : mm)


Dimensions	Individual mounting
<p>The front panel dimensions are 96.0 mm wide by 96.0 mm high. The display area is 81.4 mm wide by 96.0 mm high. The keypad area is 13.5 mm wide by 96.0 mm high. The bottom section is 13.5 mm wide by 1.0 mm high.</p>	<p>The mounting fixture dimensions are 81.4 mm wide by 90.0 mm high. The fixture has a thickness of 1.0 mm. The mounting fixture height is 121.0 mm. The panel thickness is t (1~t~6 mm).</p>

7. Terminal Arrangement


⚠ Warning

Turn the power supply to the instrument off before wiring or checking.
Working on or touching the terminal with the power switched on may result in severe injury or death due to electric shock.

7.1 WT404 Terminal Arrangement




7.2 WT904 Terminal Arrangement




Power	1 L AC 85~265V 2 N 1 - 2 + 1 - DC 24V 2 +	14 T/R (B-) RS-485 15 T/R (A+)
Output-1	8 NO 9 NC 10 COM 9 + 10 - 9 + 10 - 9 + 10 -	12 + mA / V 13 - mA / V 14 + mA / V 15 - mA / V
Output-2	6 + 7 - Relay 6 + 7 - SSR 6 + 7 - mA / V	14 + mA / V 15 - mA / V 14 + mA / V 15 - mA / V
Motor valve	6 7 CLOSE 8 OPEN 9 10 COM	11 COM 12 NO 13 NO 14 COM 15 NO 16 NO DI1 DI2 DI3
Alarm-1 Alarm-2 Alarm-3	3 NC 4 NO 5 COM 11 NC 12 NO 13 COM 16 17 18 19 mA / V 20 - mA / V 17 B 19 B 20 A RTD mA / V	17 B 19 B 20 A RTD mA / V 14 + TC / mV 15 - TC / mV 14 + mA / V 15 - mA / V 16 B RTD mA / V

7.3 WT707 Terminal Arrangement




Power		
Output-1		
Output-2		
1φ Zero cross/ Phase angle		
Motor valve		

7.4 WT409 Terminal Arrangement



Power	1 L AC 85~265V 2 N 1 - DC 24V 2 +	Communication	14 T/R (B-) RS-485 15 T/R (A+)
Output-1	8 NO 9 NC 10 COM	Transmission	12 + mA / V 13 - mA / V 14 + mA / V 15 - mA / V
Output-2	6 NO 7 NO Relay 6 + mA / V 6 + mA / V 7 - mA / V	Remote SV/ CT Input	14 + mA / V 15 - mA / V 14 + mA / V 15 - mA / V
Motor valve	6 CLOSE 7 OPEN 8 9 10 COM	Digit Input	11 COM 12 NO 13 NO 14 COM 15 NO 16 NO
Alarm-1 Alarm-2 Alarm-3	3 NC 4 NO 5 COM 11 NC 12 NO 13 COM 6 NO 7 NO	Input 1	17 B 19 + TC / mV 20 - TC / mV 17 + mA / V 20 - mA / V
		Input 2	14 + TC / mV 15 - TC / mV 14 + mA / V 15 - mA / V 16 B

7.5 WT909 Terminal Arrangement



8. Basic Function Setting

8.1 Change Input Type

1.	PV SV	Display after power-on.	2.	PV SV	Hold SET key + key 3 seconds, to enter LEVEL_3 upper display showing "INPT" with lower display showing current input type.
3.	PV SV	Press key the lower display flashes.	4.	PV SV	Press key and key to enter the intended input type.
5.	PV SV	Press SET key to store new value of INPT.			Modify input type needs to interchange of jumper location, and it needs to recalibration for linear input type change. Please refer to chapter 15 "modification of Input signal" .

8.2 SV Setting

1.	PV SV	Display after power-on.	2.	PV SV	When key is pressed, the lower display flashes.
3.	PV SV	Press key and key to adjust set value.	4.	PV SV	Press SET key to store new value of SV.

8.3 RUN/STOP Mode Selection

1.	PV SV	Display after power-on.	2.	PV SV	Press SET key to enter parameter setup display, with "R_S" shown on the upper display.
3.	PV SV	When key is pressed, the lower display flashes.	4.	PV SV	Press key or key to select RUN/STOP mode.
5.	PV SV	Press SET key to store new value of R_S.			When controller is in STOP mode, it disable OUTPUT and ALARM functions.

8.4 Setting PID Value Automatically(Auto-tunning)

1.	PV SV	Display after power-on.	2.	PV SV	Press SET key to get parameter setup display, as "OFF" will be shown on the upper display.
3.	PV SV	When key is pressed, the lower display flashes.	4.	PV SV	Press key or key to select auto tuning execution or not.
5.	PV SV	Press SET key to store new value of AT.			When auto-tuning AT LED lamp lit and start to output, through a few circles to get new PID value with the precise control, if finished the AT LED will be lamp off.

8.5 Setting PID Value Manually

1.	PV Display after power-on.	2.	PV Hold SET key 3 seconds, then entering into LEVEL_2 upper display showing "P1", with lower display showing PV 8885 SV 8880
3.	PV When ◀ key is pressed, the lower display flashes.	4.	PV Press A key and V key to set the intended P1 value.
5.	PV Press SET key to store new value of P1.		By the same procedure, use the same ways to set integral time(I1) and derivative time(D1).

8.6 Controlling With ON/OFF Action

1.	PV Display after power-on.	2.	PV Hold SET key 3 seconds, then entering into LEVEL_2, as upper display shows "P1", with lower display showing current P1 value.
3.	PV When ◀ key is pressed, the lower display flashes, upper display.	4.	PV Press V key until P1 = 0.0
5.	PV Press SET key to store new value.	6.	PV Press SET key to get parameter setup display, "HYS1" shown on the upper display.
7.	PV When ◀ key is pressed, the lower display flashes.	8.	PV Press A key and V key to set the intended HYS1 value.
9.	PV Press SET key to store new value.		Heat mode formula: $PV \geq (SV + HYS1) \rightarrow OUT1 OFF$ $PV \leq (SV - HYS1) \rightarrow OUT1 ON$ Cool mode formula: $PV \geq (SV + HYS1) \rightarrow OUT1 ON$ $PV \leq (SV - HYS1) \rightarrow OUT1 OFF$

8.7 Alarm Mode Setting

1.	PV Display after power-on.	2.	PV Hold SET key + ◀ key 3 seconds, then entering into LEVEL_3 upper display showing "INPT" with lower display showing current input type.
3.	PV Press SET key to get parameter setup display, with "ALD1" shown on the upper display.	4.	PV When ◀ SHIFT key is pressed, the lower display flashes.
5.	PV Press A key and V key to set the intended ALD1 value.	6.	PV Press SET key to store new value of ALD1. Please refer to Chapter 12.1 Alarm mode .

8.8 Alarm Value Setting

1.	PV SV	Display after power-on.	2.	PV SV	Press SET key to get parameter setup display, with "AL1H" shown on the upper display.
3.	PV SV	When key is pressed, the lower display flashes.	4.	PV SV	Press key and key to set the intended AL1H value.
5.	PV SV	Press SET key to store new value of AL1H.			

8.9 Controlling With Manual Control

1.	PV SV	Display after power-on.	2.	PV SV	Press SET key to get parameter setup display, with "A_M" shown on the upper display.
3.	PV SV	When key is pressed, the lower display flashes.	4.	PV SV	Press key or key to select AUTO/MMAN mode.
5.	PV SV	Press SET key to store new value of A_M.	6.	PV SV	Press SET key to get parameter setup display, with "MOUT" shown on the upper display.
7.	PV SV	When key is pressed, the lower display flashes.	8.	PV SV	Press key and key to set the intended MOUT value.
9.	PV SV	Press SET key to store new value of MOUT.			In manual mode and MOUT=100.0, output=100.0% continuously. In manual mode and MOUT=20.0, output=20.0% continuously.


9. Flow Chart Of Parameter Setting

9.1 Parameter Structure

The WT controller is an original dual-loop controller. The parameter group of Level 1~Level 4 is of LOOP type.

There are two copies kept in LOOP1 and LOOP2.


Level 5 parameter group non-LOOP type is of an independent, linked with Level 4 of LOOP1 or LOOP2, as the parameter structure is shown in the diagram below.



9.2 Level Operation Mode

1. LEVEL 1 enter to the LEVEL 2
Hold SET key for 3 seconds then entering into LEVEL 2
2. LEVEL 1 enter to the LEVEL 3
Hold SET key + SHIFT key for 3 seconds then entering into LEVEL 3
3. LEVEL 2 return to the LEVEL 1
Hold SET key for 3 seconds then return to LEVEL 1
4. LEVEL 2 enter to the LEVEL 3
Hold SET key for 3 seconds then return to LEVEL 3
5. LEVEL 1 enter to the LEVEL 4
Hold SET key for 3 seconds then entering into LEVEL 2, in LEVEL 2
press SET key to find parameter “LOCK”, modify LOCK value from current value to 1111
then hold SET key + SHIFT key for 3 seconds then entering into LEVEL 4
6. LEVEL 2 enter to the LEVEL 5
Hold SET key for 3 seconds then entering into LEVEL 2, in LEVEL 2
press SET key to find parameter “LOCK”, modify LOCK value from current value to 1000
then hold SET key + SHIFT key for 3 seconds then entering into LEVEL 5
7. LEVEL 3 return to the LEVEL 1
hold SET key + SHIFT key for 3 seconds then return to LEVEL 1
8. LEVEL 3 return to the LEVEL 2
Hold SET key for 3 seconds then return to LEVEL 2
9. LEVEL 4 return to the LEVEL 1
Hold SET key + SHIFT key for 3 seconds then return to LEVEL 1
10. LEVEL 4 return to the LEVEL 2
Hold SET key for 3 seconds then return to LEVEL 2
11. LEVEL 5 return to the LEVEL 1
Hold SET key + SHIFT key for 3 seconds then entering into LEVEL 1
12. LEVEL 5 return to the LEVEL 2
Hold SET key for 3 seconds then return to LEVEL 2

9.3 Level Operation Diagram



※ : If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.


9.4 Data Lock Function

LOCK provides a parameter protection function to prevent the operator from touching or modifying important parameters. Conversely, when the parameter cannot be modified, please check that the set value of LCK.

LOCK	LEVEL					Descriptions
	Level_1 USER Level	Level_2 PID Level	Level_3 INPUT Level	Level_4 SET Level	Level_5 QC Level	
0000	◎	◎	◎	X	X	All parameters of Level 1, 2 & 3 are able to be modified (Factory default setting)
1111	◎	◎	X	◎	X	All parameters of Level 1, 2 & 4 are able to be modified
1000	◎	◎	X	X	◎	All parameters of Level 1, 2 & 5 are able to be modified
0001	◎	◎	X	X	X	Only SV, LOOP, R_S, A_M,LOCK can be modified
0101	◎	◎	X	X	X	Only LOCK can be modified
0110	◎	◎	X	X	X	Only parameters of Level 1 and LOCK can be modified
Other	◎	◎	◎	X	X	Once jumping to other levels, LOCK will be automatically restored to 0000

◎ : allow X : inhibit

9.5 Level 1 (User Level) All Parameters Display



※ If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.


9.6 LEVEL_1 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
PV	---	Process value	USPL	LSPL	---	---
SV	---	Set value	USPL	LSPL	0	---
LOOP		Loop selection 0 : LOP1 (loop1) 1 : LOP2 (loop2)	LOP2	LOP1	LOP1	SET6.4
R_S		RUN/STOP mode selection 0 : STOP (output & alarm disable) 1 : RUN (output & alarm enable)	RUN	STOP	RUN	SET3.4
HBCU		HBA current display unit : ampere(A) Please refer to Chapter 11.4	---	---	---	SET1.1 & ALDX=HBA
HBSV		HBA current setting unit : ampere(A)	100.0	0.0	1.0	SET1.1 & ALDX=HBA
HBTM		HBA disconnection set time unit : second(S)	COTI	0.00	0.10	SET1.1 & ALDX=HBA
AL1H		Alarm1 upper set value (ALD1 = DE.HI / DE.HL / BA.ND / PR.HI / DEHI / DEHL / BAND / PRHI appear) Please refer to Chapter 12	9999	-1999	1.0	SET1.2
AL1L		Alarm1 lower set value (ALD1 = DE.LO / DE.HL / BA.ND / PR.LO / DELO / DEHL / BAND / PRLO appear)	9999	-1999	1.0	SET1.2
AL2H		Alarm2 upper set value (ALD2 = DE.HI / DE.HL / BA.ND / PR.HI / DEHI / DEHL / BAND / PRHI appear)	9999	-1999	1.0	SET1.3
AL2L		Alarm2 lower set value (ALD2 = DE.LO / DE.HL / BA.ND / PR.LO / DELO / DEHL / BAND / PRLO appear)	9999	-1999	1.0	SET1.3
AL3H		Alarm3 upper set value (ALD3 = DE.HI / DE.HL / BA.ND / PR.HI / DEHI / DEHL / BAND / PRHI appear)	9999	-1999	1.0	SET1.4
AL3L		Alarm3 lower set value (ALD3 = DE.LO / DE.HL / BA.ND / PR.LO / DELO / DEHL / BAND / PRLO appear)	9999	-1999	1.0	SET1.4
SV1		First set value (only available in DI function)	USPL	LSPL	10	SET2.1
SV2		Second set value (only available in DI function)	USPL	LSPL	20	SET2.1
SV3		Third set value (only available in DI function)	USPL	LSPL	30	SET2.2
SV4		Fourth set value (only available in DI function)	USPL	LSPL	40	SET2.2
TIM		Timer PV address use for current time SV address use for target time (only available in DI function) Please refer to Chapter 11.6	COTI	0.00	0.00	SET2.3
CNT		Counter PV address use for current count SV address use for target count (only available in DI function)	9999	0	0	SET2.4
CUTM		24 hour timer Current time Please refer to Chapter 11.8	23.59	0.00	0.00	SET3.1
ONTM		24 hour timer, ON time PV address use for display current time, SV address use for setting ON time	23.59	0.00	0.00	SET3.1
OFTM		24 hour timer, OFF time PV address use for display current time, SV address use for setting OFF time	23.59	0.00	0.00	SET3.1

9.6 LEVEL_1 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
A_M		Auto/Manual mode switch 0 : AUTO (auto mode) 1 : MMAN (main output manual mode) 2 : SMAN (sub output manual mode)	SMAN	AUTO	AUTO	SET3.2
MOUT		Manual manipulated output setting value	100.0	0.0	0.0	SET3.2
AT		Auto-tuning execute selection 0 : OFF (PID control) 1 : ON (execute auto-tuning)	ON	OFF	OFF	SET3.3
RATE		Slave SV rate RATE SV = SV x (RATE/9999)	9999	0	9999	SV.TY=RATE SV.TY=ANRA
RAMP		The rate of change during SV ramp operation format : °C / minute Please refer to Chapter 11.11	99.99	-19.99	0.00	SV.TY=RAMP & SETE.4
SOAK		Soak time Time format : min.sec	COTI	0.00	0.10	ALDX=MSOK ALDX=SOAK ALDX=FSOK
WAIT		Program execution standby temperature 0 : when program execute do not wait for PV temperature Other values : when PV= (target SV-WAIT) program entering next segment Please refer to Chapter 13	1000	0	0	SET4.1
DTM1		Reserve	99.59	0.00	0.00	SET4.2
DTM2		Reserve	99.59	0.00	0.00	SET4.2
DTM3		Reserve	99.59	0.00	0.00	SET4.2
DTM4		Reserve	99.59	0.00	0.00	SET4.2
DT.ST		Reserve	99.59	0.00	0.00	SET4.3
PTN		Program pattern selection 1~15	15	TRIP	1	SV.TY = PROG
SEG		Program segment selection 1~10	10	1	1	SV.TY = PROG
L1.SV		LOOP1 current segment target SV	USPL	LSPL	0	SV.TY = PROG
L2.SV		LOOP2 current segment target SV	USPL	LSPL	0	SV.TY=PROG & SET6.4
TIMR		Current segment execute time setting, this parameter determines the link between segment and segment or pattern and pattern END(-1) : program end in this segment 00.00 : program step change in this segment 00.01~99.58 : program in this segment execute time COTI(99.59) : program continue execute this segment no end	COTI	END	00.00	SV.TY = PROG
MOLH		Current segment output limit	100.0	0.0	100.0	SV.TY=PROG & SET6.4

9.7 Level 2 (PID Level) All Parameters Display



※ If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.


9.8 LEVEL_2 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
P1		Main output proportional band 0 : ON/OFF control Other values : proportional band setting value	200.0	0.0	3.0	---
I1		Main output integral time 0 : disable integral function Other values : integral time setting value	3600	0	240	---
D1		Main output derivative time 0 : disable derivative function Other values : derivative time setting value	900	0	60	---
HYS1		Hysteresis for main output on/off control use(when P1 = 0.0 appear) heating formula : PV ≥ (SV + HYS1) → OUT1=OFF PV ≤ (SV - HYS1) → OUT1=ON cooling formula : PV ≥ (SV + HYS1) → OUT1=ON PV ≤ (SV - HYS1) → OUT1=OFF	100.0	-100.0	1.0	P1 = 0.0
CYT1		Main output control cycle 0 : Linear signal 1 : SSR drive 2~150 : Relay	150	0	10	---
MOLH		High limit setting of manipulated value for main output	100.0	0.0	100.0	SET5.2
MOLL		Low limit setting of manipulated value for main output	100.0	0.0	0.0	SET5.2
P2		Sub output proportional band 0 : ON/OFF control Other values : proportional band setting value	200.0	0.0	3.0	OU.TY = DOUB
I2		Sub output integral time 0 : disable integral function Other values : integral time setting value	3600	0	240	OU.TY = DOUB
D2		Sub output derivative time 0 : disable derivative function Other values : derivative time setting value	900	0	60	OU.TY = DOUB
HYS2		Hysteresis for sub output on/off control(when P2 = 0.0 appear)	100.0	-100.0	1.0	P2 = 0.0
CYT2		Sub output control cycle 0 : Linear signal 1 : SSR drive 2~150 : Relay	150	0	10	OU.TY = DOUB
SOLH		High limit setting of manipulated value for sub output	100.0	0.0	100.0	SET5.4
SOLL		Low limit setting of manipulated value for sub output	100.0	0.0	0.0	SET5.4
MGAP		Control gap (for main output)	1000	-1000	0	OU.TY = DOUB
SGAP		Control gap (for sub output)	1000	-1000	0	OU.TY = DOUB
COUT		Current manipulated output value	100.0	0.0	---	SET6.1
AT.VL		Auto-tuning offset value execute auto-tuning in (SV-ATVL) point	100.0	-100.0	0.0	SET6.2
SS.PO		If SETF.2=0, in manual mode or error condition controller will load this setting value as manipulated value.	100.0	0.0	25.0	SET6.2

9.8 LEVEL_2 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MAX		
OPSF		Main output special function selection 0 : NONE (special function OFF) 1 : SQUA (manipulated output value square) 2 : ROOT (manipulated output value square root) 3 : REVE (manipulated output value reverse) 4 : SQ.RE (manipulated output value square reverse) 5 : RO.RE (manipulated output value square root reverse)	RO.RE	NONE	NONE	SET6.3
RC.TO		Output filter Unit : second	10.00	1.00	2.00	SET6.3
LOCK		Function/level lock Please refer to Chapter 9.4	1111	0000	0000	0000

9.9 Level 3 (Input Level) All Parameters Display



※ If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.


9.10 LEVEL_3 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
INPT		Input type selection (please refer to Chapter 3 Input Range Table)	AN6	K1	K1	---
AN.LO		Analog input zero calibration, only available in linear input Please refer to Chapter 15.3	9999	-1999	0	SET7.1
AN.HI		Analog input span calibration, only available in linear input, hex display Please refer to Chapter 15.3	0x7FFF	0x0000	0x5FFF	SET7.1
DP		Decimal point position (only available in linear signal input) 0 : 0000 1 : 000.0 2 : 00.00 3 : 0.000	0.000	0000	0000	SET7.1
HI.RA		Input scale high(for analog input)	9999	-1999	---	SET7.2
LO.RA		Input scale low(for analog input)	9999	-1999	---	SET7.2
USPL		Input scale high (for Thermocouple or RTD)	9999	-1999	---	SET7.3
LSPL		Input scale low (for Thermocouple or RTD)	9999	-1999	---	SET7.3
ALD1		Alarm1 mode selection (Please refer to Chapter 12.1 Alarm Mode)	FSOK	NONE	DEHI	SET7.4
ALT1		FLIK (00.00) : Flicker COTI (99.59) : Continued ON 00.01~99.58 : delay time	COTI	FLIK	COTI	SET7.4
HYA1		Hysteresis setting for alarm1	999.9	-199.9	1.0	SET7.4
SEA1		Alarm1 special function setting (Please refer to Chapter 12.2 Alarm Special Setting)	1111	0000	0000	SET7.4
ALD2		Alarm2 mode selection (Please refer to Chapter 12.1 Alarm Mode)	FSOK	NONE	NONE	SET8.1
ALT2		FLIK (00.00) : Flicker COTI (99.59) : Continued ON 00.01~99.58 : delay time	COTI	FLIK	COTI	SET8.1
HYA2		Hysteresis setting for alarm 2	999.9	-199.9	1.0	SET8.1
SEA2		Alarm2 special function setting (Please refer to Chapter 12.2 Alarm Special Setting)	1111	0000	0000	SET8.1
ALD3		Alarm3 mode selection (Please refer to Chapter 12.1 Alarm Mode)	FSOK	NONE	NONE	SET8.2
ALT3		FLIK (00.00) : Flicker COTI (99.59) : Continued ON 00.01~99.58 : delay time	COTI	FLIK	COTI	SET8.2
HYA3		Hysteresis setting for alarm 3	999.9	-199.9	1.0	SET8.2
SEA3		Alarm3 special function setting (Please refer to Chapter 12.2 Alarm Special Setting)	1111	0000	0000	SET8.2
MOCL		Main output zero calibration only available for linear signal Please refer to Chapter 14.5	9999	0	0	SET8.3
MOCH		Main output span calibration only available for linear signal Please refer to Chapter 14.5	9999	0	3600	SET8.3
SOCL		Sub output zero calibration only available for linear signal	9999	0	0	SET8.4
SOCH		Sub output span calibration only available for linear signal	9999	0	3600	SET8.4

9.10 LEVEL_3 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
MV.SF	245F	Analog input special function selection 0 : NONE (special function OFF) 1 : SQUA (analog input square) 2 : ROOT (analog input square root) 3 : REVE (analog input reverse) 4 : SQ.RE (analog input square reverse) 5 : RO.RE (analog input square root reverse)	RO.RE	NONE	NONE	SET9.1
RC.TI	ACB0	Input digital filter Unit : second	10.00	1.00	2.00	SET9.2
UNIT	UNRE	Unit 0 : °C 1 : °F 2 : U (Linear signal)	2	0	---	SET9.3
OUTM	00E0	Control action selection 0 : HEAT (reverse action) 1 : COOL (direct action)	COOL	HEAT	HEAT	SET9.4
SV.OS	5005	SV bias	100.0	-100.0	0	SETA.1
PV.OS	P005	PV bias(for zero) PV = PV x (PV.OH / 5000) + PV.OS Please refer to Chapter 11.1	199.9	-199.9	0	SETA.2
PV.OH	P00H	PV bias(for span) PV = PV x (PV.OH / 5000) + PV.OS	9999	0	5000	SETA.2
MLNB	010B	Piece linear compensation segment select TRIP : leave setting loop 1~10 : segment select Please refer to Chapter 11.10	10	TRIP	TRIP	SETA.3
COMP	C00P	Piece linear compensation compare value	USPL	LSPL	LSPL	SETA.3
OFFS	0FFS	Piece linear compensation offset value	150.0	-150.0	0.0	SETA.3

9.11 Level 4 (Setting Level) All Parameters Display



※ If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.


9.12 LEVEL_4 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
SV.TY		SV source selection LOOP1 0 : FIX (local SV) 1 : RATE (uart data x RATE/9999) 2 : RAMP (ramp SV) 3 : CASC (cascade control) 4 : ANAG (remote SV) 5 : ANRA (remote SV x RATE/9999) 6 : PROG (program SV)	PROG	FIX	FIX	---
		LOOP2 0 : FIX (local SV) 1 : RATE (uart data x RATE/9999) 2 : RAMP (ramp SV) 3 : CASC (cascade control)				
OU.TY		Hardware drive selection LOOP1 0 : SING (single output) 1 : DOUB (dual output) 2 : 1SCR (single phase control) 3 : HLSL (high low signal selection) 4 : FBMV (valve control with feedback) 5 : NFMV (valve control without feedback)	NFMV	SING	SING	SETB.1
		LOOP2 0 : SING (single output) 1 : DOUB (dual output) 2 : 1SCR (single phase control) 3 : HLSL (high low signal selection) 4 : NFMV (valve control without feedback)				
PMAC		Automatic valve position adjustment 0 : OFF stop automatic adjust 1 : ON start automatic adjust 2 : E_PB Valve position determined by external button	E_PB	OFF	OFF	OU.TY = FBMV
FKSL		A/M key function mode selection 0 : OFF (disable A/M key) 1 : R_S (switch RUN/STOP) 2 : A_M (switch auto/manual) 3 : AT (ON/OFF auto-tuning) 4 : LOOP (switch LOOP1/2) Please refer to Chapter 11.5	LOOP	OFF	A_M	SETB.3
BIAS		Reserve	1000	-1000	0	SETB.4
TP_K		Reserve	100.0	10.0	15.0	SETB.4
TMSL		24 hour timer, mode selection 0 : OFF (24 hour timer function disable) 1 : SWSV (switch SV) 2 : R_S (switch RUN/STOP) 3 : R_SO (switch to run)	R_SO	OFF	OFF	SETC.1
MVRT		Motor valve traveling time Time unit : second (Please refer to Chapter 11.9)	150	5	5	OU.TY=FBMV & SETC.2
HYSM		Motor valve action main adjustment unit : percentage	5.0	0.0	1.0	OU.TY=FBMV & SETC.2
RH.TC		Dehumidification temperature If PV less than RHTC manipulated value = RHPO (Please refer to Chapter 11.7)	200.0	0.0	125.0	SETC.3
RH.PO		Dehumidification manipulated value 0 : OFF disable dehumidification function Other values : 0.1~100.0 manipulated value	100.0	OFF	OFF	SETC.3

9.12 LEVEL_4 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
RH.TM	PR50	Dehumidification time time format : min.sec	COTI	0.00	15.00	SETC.3
PR.SV	PR50	Reserve	USPL	LSPL	100.0	SETC.4
HBOP	HBOA	Output percentage of trigger HBA	100.0	0.0	90.0	SET1.1
SET1	SEE1	Parameters Hide/Display	4369	0	---	---
SET2	SEE2	Parameters Hide/Display	4369	0	---	---
SET3	SEE3	Parameters Hide/Display	4369	0	---	---
SET4	SEE4	Parameters Hide/Display	4369	0	---	---
SET5	SEE5	Parameters Hide/Display	4369	0	---	---
SET6	SEE6	Parameters Hide/Display	4369	0	---	---
SET7	SEE7	Parameters Hide/Display	4369	0	---	---
SET8	SEE8	Parameters Hide/Display	4369	0	---	---
SET9	SEE9	Parameters Hide/Display	4369	0	---	---
SETA	SEEA	Parameters Hide/Display	4369	0	---	---
SETB	SEEB	Parameters Hide/Display	4369	0	---	---
SETC	SEEC	Parameters Hide/Display	4369	0	---	---
SETD	SEED	Parameters Hide/Display	4369	0	---	---
SETE	SEEF	Parameters Hide/Display	4369	0	---	---
SETF	SEEF	Parameters Hide/Display	4369	0	---	---

9.13 Level 5 (Quality Control) All Parameters Display



※ If no key is pressed within 60 seconds, it will automatically return to LEVEL 1 (user level) and display PV/SV.

9.14 LEVEL_5 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
HZ		Power frequency 0 : 50HZ 1 : 60HZ	60HZ	50HZ	60HZ	---
PRTO		Protocol selection 0 : Shihlin Electric 1 : MRTU (Please refer to Communication Manual)	MRTU	Shihlin Electric	MRTU	SETD.1
FOMA		Data format 0 : O_81 (parity bit=odd, stop bit=1) 1 : O_82 (parity bit=odd, stop bit=2) 2 : E_81 (parity bit=even, stop bit=1) 3 : E_82 (parity bit=even, stop bit=2) 4 : N_81 (parity bit=none, stop bit=1) 5 : N_82 (parity bit=none, stop bit=2)	N_82	O_81	O_81	SETD.1
IDNO		Controller address	254	0	1	SETD.1
BAUD		Baud rate 0 : 24(2400) 1 : 48(4800) 2 : 96(9600) 3 : 192(19200) 4 : 384(38400) 5 : 576(57600) 6 : 1152(115200) bps	1152	24	384	SETD.1
RPDT		Response delay time(ms) When controller receive master command will delay this setting value then response master	250	0	0	SETD.1
AOEN		Retransmission function enable 0 : OFF (Disable) 1 : ON (Enable) (Please refer to Chapter 11.2)	ON	OFF	OFF	SETD.2
AOSL		Retransmission output signal source selection 0 : SV1 (Loop1 SV) 1 : PV1 (Loop1 PV) 2 : MV1 (Loop1 main out manipulated value) 3 : SV1R (Loop1 SV reverse) 4 : PV1R (Loop1 PV reverse) 5 : MV1R (Loop1 main out manipulated reverse value) 6 : SV2 (Loop2 SV) 7 : PV2 (Loop2 PV) 8 : MV2 (Loop2 main out manipulated value) 9 : SV2R (Loop2 SV reverse) 10 : PV2R (Loop2 PV reverse) 11 : MV2R (Loop2 main out manipulated reverse value)	MV2R	SV1	PV1	SETD.2
AO.LO		Retransmission output scale low	USPL	LSPL	LSPL	SETD.2
AO.HI		Retransmission output scale high	USPL	LSPL	USPL	SETD.2
AOCL		For retransmission zero calibration	9999	0	0	SETD.2
AOCH		For retransmission span calibration	9999	0	3600	SETD.2
CTRT		Reserve	100	1	1	SETD.3

9.14 LEVEL_5 Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
D1SL		LOOP1 digital input function selection 0 : OFF (disable digital input function) 1 : SWSV (switch 4 sets of SV) 2 : R_S (switch RUN/STOP) 3 : A_M (switch Auto/Manual) 4 : AT (ON/OFF auto-tunning) 5 : RESV (ON/OFF remote SV) 6 : AOEN (ON/OFF retransmission) 7 : TIM (ON/OFF timer) 8 : CNT(counter) 9 : PROG (run/reset program) (Please refer to Chapter 11.6)	PROG	OFF	OFF	SETD.3
D2SL		LOOP2 digital input function selection 0 : OFF (disable digital input function) 1 : SWSV (switch 4 sets of SV) 2 : R_S (switch RUN/STOP) 3 : A_M (switch Auto/Manual) 4 : AT (ON/OFF auto-tunning) 5 : RESV (ON/OFF remote SV) 6 : AOEN (ON/OFF retransmission) 7 : TIM (ON/OFF timer) 8 : CNT(counter)	CNT	OFF	OFF	SETD.3
REMO		Program execute via remote control OFF : program execute by key ON : program execute by digital input or communication	ON	OFF	OFF	SETD.4
CJSL		Cold junction compensation mode selection 0 : AUTO (auto cold junction compensation) 1 : MAN (manual cold junction compensation)	MAN	AUTO	AUTO	SETE.1
CJMN		Manual cold junction temperature setting	50.0	-10.0	25	SETE.1
CJTC		Current cold junction temperature display	---	---	---	SETE.1
W_MD		EEPROM protection 0 : OFF communication write command only write to CPU RAM 1 : ON communication write command write to CPU RAM and EEPROM	ON	OFF	ON	SETE.1
RMAP		Registered mapping 0 : OFF (disable registered mapping) 1 : FY (mapping to FY series memory address) 2 : FE (mapping to FE series memory address) 3 : FA (mapping to FA series memory address)	5	0	0	SETE.1
OPSL		Loop hardware distribution 0 : LOP1 loop1 main out drive out1 hardware, sub out drive out2 hardware (use for dual output) 1 : LOP2 loop2 main out drive out1 hardware, sub out drive out2 hardware (use for dual output) 2 : LP12 loop1 main out drive out1 hardware, loop2 main out drive out2 hardware (use for single output)	LP12	LOP1	LP12	SETE.1

9.14 LEVEL_5 Parameter


Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
POTM	<i>Potm</i>	System steady state time output and alarm function will enable after waiting for this setting value when power-on	COTI	0.00	0.05	SETE.1
PTMD	<i>Ptmd</i>	Program time format 0 : SEC (minute.second) 1 : MIN (hour.minute) 2 : 50MS (50ms)	50MS	SEC	MIN	SETE.1
PVST	<i>Pvst</i>	Program execute start address 0 : OFF (execute from zero) 1 : ON (execute from current PV)	ON	OFF	ON	SETE.1
REPT	<i>Rept</i>	Program execute repeat 0 : OFF (disable repeat function) Other : Program execute repeat number of times	9999	OFF	OFF	SETE.1
POWF	<i>Powf</i>	Program execute power fail protection 0 : OFF (disable power fail protection) 1 : ON (enable power fail protection)	ON	OFF	OFF	SETE.1
D01	<i>Pd01</i>	Reserve	32767	-32768	0	SETE.2
D02	<i>Pd02</i>	Reserve	32767	-32768	0	SETE.2
D03	<i>Pd03</i>	Reserve	32767	-32768	0	SETE.2
D04	<i>Pd04</i>	Reserve	32767	-32768	0	SETE.2
D05	<i>Pd05</i>	Reserve	32767	-32768	0	SETE.2
D06	<i>Pd06</i>	Reserve	32767	-32768	0	SETE.2
D07	<i>Pd07</i>	Reserve	32767	-32768	0	SETE.2
D08	<i>Pd08</i>	Reserve	32767	-32768	0	SETE.2
D09	<i>Pd09</i>	Reserve	32767	-32768	0	SETE.2
D10	<i>Pd10</i>	Reserve	32767	-32768	0	SETE.2
D11	<i>Pd11</i>	Reserve	32767	-32768	0	SETE.2
D12	<i>Pd12</i>	Reserve	32767	-32768	0	SETE.2
D13	<i>Pd13</i>	Reserve	32767	-32768	0	SETE.2
D14	<i>Pd14</i>	Reserve	32767	-32768	0	SETE.2
D15	<i>Pd15</i>	Reserve	32767	-32768	0	SETE.2
D16	<i>Pd16</i>	Reserve	32767	-32768	0	SETE.2
D17	<i>Pd17</i>	Reserve	32767	-32768	0	SETE.2
D18	<i>Pd18</i>	Reserve	32767	-32768	0	SETE.2
D19	<i>Pd19</i>	Reserve	32767	-32768	0	SETE.2
D20	<i>Pd20</i>	Reserve	32767	-32768	0	SETE.2

9.15 Fast Parameter Access

WT controller provides a fast parameter access operation, easy for users to quickly access communication group, program group, motor valve group related parameters

Enter fast parameter access operation: press down key for 3 seconds at any level

Leave fast parameter access operation: press down key for 3 seconds at fast level




9.16 Fast Level Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
INPT		Input type selection (please refer to Chapter 3 Input Range Table)	AN6	K1	K1	---
MVRT		Motor valve traveling time Time unit : second (Please refer to Chapter 11.9)	150	5	5	OU.TY=FBMV & SETC.2
CYT1		Motor valve action interval time. Time unit : second	10	0	5	---
HYSM		Motor valve action main adjustment unit : percentage	5.0	0.0	1.0	OU.TY=FBMV & SETC.2
HYS1		Motor valve action sub adjustment unit : percentage	HYSM	0.0	0.5	OU.TY=FBMV or OU.TY=NFMV
PMAC		Automatic valve position adjustment 0 : OFF stop automatic adjust 1 : ON start automatic adjust 2 : E_PB Valve position determined by external button	E_PB	OFF	OFF	OU.TY=FBMV
RH.TC		Dehumidification temperature If PV less than RHTC manipulated value = RHPO (Please refer to Chapter 11.7)	200.0	0.0	125.0	SETC.3
RH.PO		Dehumidification manipulated value 0 : OFF disable dehumidification function Other values : 0.1~100.0 manipulated value	100.0	OFF	OFF	SETC.3
RH.TM		Dehumidification time time format : min.sec	COTI	0.00	15.00	SETC.3
PRTO		Protocol selection 0 : Shihlin Electric 1 : MRTU (Please refer to Communication Manual)	MRTU	Shihlin Electric	MRTU	SETD.1
FOMA		Data format 0 : O_81 (parity bit=odd, stop bit=1) 1 : O_82 (parity bit=odd, stop bit=2) 2 : E_81 (parity bit=even, stop bit=1) 3 : E_82 (parity bit=even, stop bit=2) 4 : N_81 (parity bit=none, stop bit=1) 5 : N_82 (parity bit=none, stop bit=2)	N_82	O_81	O_81	SETD.1
IDNO		Controller address	254	0	1	SETD.1
BAUD		Baud rate 0 : 24(2400) 1 : 48(4800) 2 : 96(9600) 3 : 192(19200) 4 : 384(38400) 5 : 576(57600) 6 : 1152(115200) bps	1152	24	384	SETD.1
RPDT		Response delay time(ms) When controller receive master command will delay this setting value then response master	250	0	0	SETD.1

9.16 Fast Level Parameter

Parameter	Symbol	Content	Range		Default	Hide/Display
			MAX	MIN		
RMAP		Registered mapping 0 : OFF (disable registered mapping) 1 : FY (mapping to FY series memory address) 2 : FE (mapping to FE series memory address) 3 : FA (mapping to FA series memory address)	5	0	0	SETE.1
PTMD		Program time format 0 : SEC (minute.second) 1 : MIN (hour.minute) 2 : 50MS (50ms)	50MS	SEC	MIN	SETE.1
PVST		Program execute start address 0 : OFF (execute from zero) 1 : ON (execute from current PV)	ON	OFF	ON	SETE.1
REPT		Program execute repeat 0 : OFF (disable repeat function) Other : Program execute repeat number of times	9999	OFF	OFF	SETE.1
POWF		Program execute power fail protection 0 : OFF (disable power fail protection) 1 : ON (enable power fail protection)	ON	OFF	OFF	SETE.1
HBOP		Output percentage of trigger HBA	100.0	0.0	90.0	SET1.1

10. Parameters Hide/Display Table On Level 4



SEE2	SET1_1	0	hide	HBCU HBSV HBTM HBOP
		1	display	HBCU HBSV HBTM HBOP
	SET1_2	0	hide	AL1H AL1L
		1	display	AL1H AL1L
	SET1_3	0	hide	AL2H AL2L
		1	display	AL2H AL2L
	SET1_4	0	hide	AL3H AL3L
		1	display	AL3H AL3L

SEE2	SET2_1	0	hide	SV1 SV2
		1	display	SV1 SV2
	SET2_2	0	hide	SV3 SV4
		1	display	SV3 SV4
	SET2_3	0	hide	TIM
		1	display	TIM
	SET2_4	0	hide	(CNT→ LOOP1) (PW→ LOOP2)
		1	display	(CNT→ LOOP1) (PW→ LOOP2)

SEE3	SET3_1	0	hide	CUTM ONTM OFTM
		1	display	CUTM ONTM OFTM
	SET3_2	0	hide	A_M
		1	display	A_M
	SET3_3	0	hide	AT
		1	display	AT
	SET3_4	0	hide	R_S
		1	display	R_S

SEE4	SET4_1	0	hide	WAIT
		1	display	WAIT
	SET4_2	0	hide	DTM1 DTM2 DTM3 DTM4
		1	display	DTM1 DTM2 DTM3 DTM4
	SET4_3	0	hide	DT.ST
		1	display	DT.ST
	SET4_4	0	hide	PV1 PV2
		1	display	PV1 PV2

SEE5	SET5_1	0	hide	reserve
		1	display	reserve
	SET5_2	0	hide	MOLH MOLL
		1	display	MOLH MOLL
	SET5_3	0	hide	reserve
		1	display	reserve
	SET5_4	0	hide	SOLH SOLL
		1	display	SOLH SOLL

SEE6	SET6_1	0	hide	COUT
		1	display	COUT
	SET6_2	0	hide	AT.VL SS.PO
		1	display	AT.VL SS.PO
	SET6_3	0	hide	OPSF RC.TO
		1	display	OPSF RC.TO
	SET6_4	0	hide	LOOP L2.SV MOLH
		1	display	LOOP L2.SV MOLH

SEE7	SET7_1	0	hide	AN.LO AN.HI DP
		1	display	AN.LO AN.HI DP
	SET7_2	0	hide	HI.RA LO.RA
		1	display	HI.RA LO.RA
	SET7_3	0	hide	LSPL USPL
		1	display	LSPL USPL
	SET7_4	0	hide	ALD1 ALT1 HYA1 SEA1
		1	display	ALD1 ALT1 HYA1 SEA1

SEE8	SET8_1	0	hide	ALD2 ALT2 HYA2 SEA2
		1	display	ALD2 ALT2 HYA2 SEA2
	SET8_2	0	hide	ALD3 ALT3 HYA3 SEA3
		1	display	ALD3 ALT3 HYA3 SEA3
	SET8_3	0	hide	MOCL MOCH
		1	display	MOCL MOCH
	SET8_4	0	hide	SOCL SOCH
		1	display	SOCL SOCH

SEE9	SET9_1	0	hide	MV.SF
		1	display	MV.SF
	SET9_2	0	hide	RC.TI
		1	display	RC.TI
	SET9_3	0	hide	UNIT
		1	display	UNIT
	SET9_4	0	hide	OUTM
		1	display	OUTM

SEE8	SETA_1	0	hide	SV.OS
		1	display	SV.OS
	SETA_2	0	hide	PV.OS PV.OH
		1	display	PV.OS PV.OH
	SETA_3	0	hide	MLNB COMP OFFS
		1	display	MLNB COMP OFFS
	SETA_4	0	hide	Super SV function disable
		1	display	Super SV function enable

SEE8	SETB_1	0	hide	OU.TY
		1	display	OU.TY
	SETB_2	0	hide	reserve
		1	display	reserve
	SETB_3	0	hide	FKSL
		1	display	FKSL
	SETB_4	0	hide	BASE TP_K
		1	display	BASE TP_K

SEE8	SETC_1	0	hide	TMSL
		1	display	TMSL
	SETC_2	0	hide	MVRT HYSM
		1	display	MVRT HYSM
	SETC_3	0	hide	RH.TC RH.PO RH.TM
		1	display	RH.TC RH.PO RH.TM
	SETC_4	0	hide	PR.SV
		1	display	PR.SV

SEE8	SETD_1	0	hide	PRTO FOMA IDNO BAUD RPDT
		1	display	PRTO FOMA IDNO BAUD RPDT
	SETD_2	0	hide	AOEN AOSL AO.LO AO.HI AOCL AOCH
		1	display	AOEN AOSL AO.LO AO.HI AOCL AOCH
	SETD_3	0	hide	CTRT D1SL D2SL
		1	display	CTRT D1SL D2SL
	SETD_4	0	hide	REMO
		1	display	REMO

SEE8	SETE_1	0	hide	CJSL CJMN CJTC W_MD RMAP OPSL POTM
		1	display	CJSL CJMN CJTC W_MD RMAP OPSL POTM
	SETE_2	0	hide	D01 D02 D03 D04 D05 D06 D07 D08 D09 D10 D11 D12 D13 D14 D15 D16 D17 D18 D19 D20
		1	display	D01 D02 D03 D04 D05 D06 D07 D08 D09 D10 D11 D12 D13 D14 D15 D16 D17 D18 D19 D20
	SETE_3	0	hide	reserve
		1	display	reserve
	SETE_4	0	hide	RAMP
		1	display	RAMP

SEE8	SETF_1	0	valve control close Relay b contact out
		1	valve control close Relay a contact out
	SETF_2	0	in abnormal condition MOUT = SS.PO
		1	in abnormal condition MOUT = 0
	SETF_3	0	PV Hysteresis_mode disable
		1	PV Hysteresis_mode enable
	SETF_4	0	disable piece linear compensation function
		1	enable piece linear compensation function


11. Functional Descriptions

11.1 Input Calibration

Description

The WT series controller offers two methods for input calibration, PV bias (PV.OS) and PV ratio (PV.OH) functions to correct the deviation of each sensor, as well as PV difference between controllers.

Functional Diagram



The related parameter of input calibration are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
PV.OS		PV bias(for zero) PV = PV x (PV.OH / 5000) + PV.OS	199.9	-199.9	0	Level 3	SETA.2
PV.OH		PV bias(for span) PV = PV x (PV.OH / 5000) + PV.OS	9999	0	5000	Level 3	SETA.2

Example 1

PV bias (PV.OS) adds bias to the Measured value(PV):

When two controllers measure the temperature of the same type of load, the measured values of the respective characteristics of the sensors are displayed as

Controller A : 200°C Controller B : 195°C

As shown above, Controller B is compensated by PV offset (PV.OS). The PV.OS parameter value must be corrected by +5°C. The display value will be changed to 200°C, Same as Controller A, but Controller B will show 5°C at 0°C.

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SETA.2	1	Display PV.OS / PV.OH
1	3	PV.OS	5	PV adds +5°C
1	3	PV.OH	5000	PV ratio unchanging

Example 2

PV ratio (PV.OH) is a multiplier to be applied to the Measured value(PV):

When two controllers measure the temperature of the same type of load, the measured values of the respective characteristics of the sensors are displayed as

Controller A : 200°C Controller B : 195°C

As shown above, if Controller B is compensated by the PV ratio (PV.OH), then the PV.OH parameter value is adjusted to display at 200°C. Consistent with Controller A, Controller B will show 0°C at 0°C.

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SETA.2	1	Display PV.OS / PV.OH
1	3	PV.OS	0	PV bias unchanging
1	3	PV.OH	5129	PV ratio=(5129/5000)=1.0258


11.2 Retransmission

Description

The retransmission function of the WT series controller can provide digital values for parameters such as SV1, PV1, MV1, SV1R, PV1R, MV1R, SV2, PV2, MV2, SV2R, PV2R, MV2R, etc.

Analog signals are transmitted to external devices according to the set range (EX: PLC AI module, inverter, etc.).
transmission output signal selectable: 4~20mA, 0~20mA, 0~5V, 0~10V, 1~5V, 2~10V

Functional Diagram



The related parameter of Transmission are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
AOEN		Retransmission function enable 0 : OFF (Disable) 1 : ON (Enable)	ON	OFF	OFF	Level 5	SETD.2
AOSL		Retransmission output signal source selection 0 : SV1 (Loop1 SV) 1 : PV1 (Loop1 PV) 2 : MV1 (Loop1 main out manipulated value) 3 : SV1R (Loop1 SV reverse) 4 : PV1R (Loop1 PV reverse) 5 : MV1R (Loop1 main out manipulated reverse value) 6 : SV2 (Loop2 SV) 7 : PV2 (Loop2 PV) 8 : MV2 (Loop2 main out manipulated value) 9 : SV2R (Loop2 SV reverse) 10 : PV2R (Loop2 PV reverse) 11 : MV2R (Loop2 main out manipulated reverse value)	MV2R	SV1	PV1	Level 5	SETD.2
AO.LO		Retransmission output scale low	USPL	LSPL	LSPL	Level 5	SETD.2
AO.HI		Retransmission output scale high	USPL	LSPL	USPL	Level 5	SETD.2
AOCL		For retransmission zero calibration	9999	0	0	Level 5	SETD.2
AOCH		For retransmission span calibration	9999	0	3600	Level 5	SETD.2

Examples

Assume the input range (LSPL & USPL) = -50.0~600.0, and the retransmission range (AO.LO & AO.HI) = 50.0~200.0, Retransmit PV1 (AOSL)


When the PV1 value is between 50.0 and 200.0, the retransmission signal is based on the PV1 value, the analog signal is presented.

When the PV1 is less than 50.0, the retransmission signal remains at 4mA

When the PV1 value is greater than 200.0, the retransmission signal remains at 20mA

Parameter Setting

LOOP	Level	Parameter	Set value	Description
---	5	AOEN	ON	Retransmission function enable
---	5	AOSL	PV1	Retransmit the PV
---	5	AO.LO	-50.0	Retransmission range lower limit
---	5	AO.HI	600.0	Retransmission range upper limit
---	5	AOCL	3133	Retransmission signal low point calibration value (each controller calibrate value is different)
---	5	AOCH	3508	Retransmission signal high point calibration value (each controller calibrate value is different)



Note

1. To order TRS function, please confirm the type of retransmission output signal and retransmit signal range
2. The user can select the source to be transmitted according to the parameter AOSL. The factory default is to retransmit the PV1.
3. Modify the parameter INPT/LSPL/USPL will reset the retransmission range AO.LO / AO.HI
4. AOCL & AOCH are the calibration parameters of the re-transmission signal. It has been calibrated before leaving the factory.
Do not change this parameter value.
5. The user only need to set AOSL / AO.LO / AO.HI three parameters, the rest of the parameters will be set and calibrated at the factory.


11.3 Remote SV

Description

Remote SV functions as an analog signal (4~20mA or 0~10V) generated by external devices (EX: PLC AO module, transmitter) to the Remote SV terminal of the controller, to change the SV(LOOP1) with a preset range.

Remote SV signal selection: 4~20mA, 0~20mA, 0~5V, 0~10V, 1~5V, 2~10V

Function Diagram



The related parameter of Remote SV are as below:


SV.TY		SV source selection LOOP1 0 : FIX (local SV) 1 : RATE (uart data x RATE/9999) 2 : RAMP (ramp SV) 3 : CASC (cascade control) 4 : ANAG (remote SV) 5 : ANRA (remote SV x RATE/9999) 6 : PROG (program SV)	PROG	FIX		Level 4	SETA.4
		Input type selection (please refer to Chapter 3 Input Range Table)	AN6	K1	K1	Level 3	---
AN.LO		Analog input zero calibration, only available in linear input (Please refer to chapter 15.3)	9999	-1999	0	Level 3	SET7.1
AN.HI		Analog input span calibration, only available in linear input, hex display (Please refer to chapter 15.3)	0x7FFF	0x0000	0x5FFF	Level 3	SET7.1
DP		Decimal point position (only available in linear signal input) 0 : 0000 1 : 000.0 2 : 00.00 3 : 0.000	0.000	0000	0000	Level 3	SET7.1
HI.RA		Input scale high(for analog input)	9999	-1999	---	Level 3	SET7.2
LO.RA		Input scale low(for analog input)	9999	-1999	---	Level 3	SET7.2

Examples

Assume LOOP1 input signal is K1 and its range is -50.0~600.0. When an external analog signal is input to the Remote SV terminal, the signal will be based on the range presents linear display of SV parameters in LOOP1

When the signal input value is less than 2.4mA, the PV position shows nnnn, indicating that the signal of Remote SV is lower than the lower limit value

When the signal input value is greater than 21.6mA, the PV position shows uuuu, indicating that the signal of Remote SV is higher than the upper limit value



Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SV.TY	ANAG	SV(LOOP1) provided by external analog signal
2	3	INPT	AN4	Remote SV input signal is 4~20mA
2	3	AN.LO	744	Remote SV signal zero calibration value (each controller calibrate value is different)
2	3	AN.HI	0x657C	Remote SV signal span calibration value (each controller calibrate value is different)
2	3	HI.RA	600.0	LOOP2 input scale high (same as USPL of LOOP1)
2	3	LO.RA	-50.0	LOOP2 input scale low (same as LSPL of LOOP1)

Notes

1. To order Remote SV function, please confirm signal type and Remote SV input range first.
2. Modify the parameter INPT & UNIT will reset the input range.
3. The AN.LO and AN.HI of LOOP2 are the calibration parameters of Remote SV. It has been calibrated before leaving the factory. Please do not change this parameter.


11.4 Heater Break Alarm

Description

The HBA (Heater-Break-Alarm) function measures the heater current and displays the measured current value on the parameter HBCU so that the heater status can be monitored at any time.

When it is detected that the heater is disconnected or the heater current is abnormally reduced, an alarm message may be immediately output to notify the user.

Function Diagram



The related parameter of Heater Break Alarm are as below :

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
HBCU		HBA current display unit : ampere(A)	---	---	---	Level 1	SET1.1 & ALDX=HBA
HBSV		HBA current setting unit : ampere(A)	100.0	0.0	1.0	Level 1	SET1.1 & ALDX=HBA
HTBM		HBA disconnection set time unit : second(S)	5999	0	10	Level 1	SET1.1 & ALDX=HBA
HBOP		Output percentage of trigger HBA	100.0	0.0	90.0	Level 4	SET1.1 & ALDX=HBA

HBA operating conditions

1. Heater current(HBCU) is less than the setting of HBSV
2. OUT1 output exceeds HBOP setting value
3. The conditions of 1 & 2 above are established and continue to exceed the set number of seconds for HTBM

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SET1.1	1	Display HBCU/HBSV/HTBM
1	3	ALD1	HBA	HBA Alarm
1	1	HBCU	---	Heater Current Value Display
1	1	HBSV	1.0	HBA Action Current Set Value (unit: A)
1	1	HTBM	10	HBA Action Time Set Value (unit: Second)
1	4	HBOP	90.0	Output percentage of trigger HBA
2	3	AN.LO	-12	Current zero calibration value (each controller calibrate value is different)
2	3	AN.HI	0x4527	Current span calibration value (each controller calibrate value is different)

Examples

Heating system with SSR as control element, set HBSV=1.0, HBTM=10, HBOP=90.0

1. The heater current display value HBCU = 0.0 when a heater disconnection occurs
→ The heater current is less than the set value of HBSV=1.0. At this time, condition 1 is satisfied.
2. The heater no longer heats when the heater disconnection occurs, and the gap between the PV and SV will become larger and larger.
→ The manipulated value of OUT1 is also getting larger and larger, and eventually exceeds 90%. At this time, condition 2 is satisfied.
3. The AL1 alarm will be activated when both 1 & 2 conditions are met and continue for more than 10 seconds of the HBOP setting.


Notes

1. To order the HBA function, please confirm the control mode, only available in SSR/RELAY control linear signal (mA or V)
Not applicable
2. AN.LO & AN.HI is the current signal calibration parameters. It has been calibrated before leaving the factory. Do not change this parameter value.
3. The user only needs to set two parameters of HBSV & HBOP, the rest of the parameters will be set & calibrated at the factory
4. CT has two specifications: SC 80-T & SC 100-T. Please check heater wire diameter and specify required CT.

CT Specifications

Item	Specifications	
Model number	SC 80-T	SC 100-T
Turns Ratio	800:1	1000:1
Max. continuous current	80A	100A
Accuracy	3%	5%
Aperture	5.9mm	12.6mm
Dielectric Withstanding Voltage(Hi-pot)	2500Vrms / 1 minute	4000Vrms / 1 minute
Vibration resistance	50 HZ, 98 m/s ²	
Weight	Approx. 12 g	Approx. 30 g

Dimensions (UNIT : mm)



11.5 A/M Key

Description

The A/M key of WT600/700/800/900 is “programmable function key”. According to the setting value of parameter FKSL, it directly operates various events on the key.

With a two-second delay to prevent users from touching it inadvertently, it takes two seconds for the event to start.

A/M Key Mode table

LOOP	Parameter	Set value	Description
✓ FKSL	R_S (1)	OFF (0)	No action
			Switch RUN/STOP mode
	A_M (2)		ON
			OFF
	AT (3)		A/M OFF
			ON
	LOOP (4)		OFF
			ON
※ FKSL of LOOP1/LOOP2 should be set as LOOP			

Example

1. Use A/M key to switch loop1 manual/auto mode

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SETB.3	1	Display loop1 FKSL
1	4	FKSL	A_M	Switch to manual/auto mode

2. Use A/M key to switch loop2 manual/auto mode

Parameter Setting

LOOP	Level	Parameter	Set value	Description
2	4	SETB.3	1	Display loop2 FKSL
2	4	FKSL	A_M	Switch to manual/auto mode

3. Use A/M key to switch loop1 run/stop mode

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SETB.3	1	Display loop1 FKSL
1	4	FKSL	R_S	Switch to RUN/STOP mode

4. Use A/M key to switch loop2 activate/stop mode

Parameter Setting

LOOP	Level	Parameter	Set value	Description
2	4	SETB.3	1	Display loop2 FKSL
2	4	FKSL	R_S	Switch to RUN/STOP mode

5. Use A/M key to switch loop1/loop2

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SETB.3	1	Display loop1 FKSL
1	4	FKSL	LOOP	Switch loop1 / loop2
2	4	SETB.3	1	Display loop2 FKSL
2	4	FKSL	LOOP	Switch loop1 / loop2

Notes


1. If the controller has DI function, please avoid setting the parameters D1SL/D2SL and FKSL to the same function mode to avoid confusion
2. A/M key factory default is A_M, switch manual/auto mode

11.6 Digital Input

Description

The WT controller provides two-point digital inputs that can be used to switch SV values through external switches or perform various events.








Function Diagram



The related parameter of Digital Input are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
D1SL		LOOP1 digital input function selection 0 : OFF (disable digital input function) 1 : SWSV (switch 4 sets of SV) 2 : R_S (switch RUN/STOP) 3 : A_M (switch Auto/Manual) 4 : AT (ON/OFF auto-tuning) 5 : RESV (ON/OFF remote SV) 6 : AOEN (ON/OFF retransmission) 7 : TIM (ON/OFF timer) 8 : CNT(counter) 9 : PROG (run/reset program)	PROG	OFF	OFF	Level 5	SETD.3
D2SL		LOOP2 digital input function selection 0 : OFF (disable digital input function) 1 : SWSV (switch 4 sets of SV) 2 : R_S (switch RUN/STOP) 3 : A_M (switch Auto/Manual) 4 : AT (ON/OFF auto-tuning) 5 : RESV (ON/OFF remote SV) 6 : AOEN (ON/OFF retransmission) 7 : TIM (ON/OFF timer) 8 : CNT(counter)	CNT	OFF	OFF	Level 5	SETD.3
SV1		First set value (only available in DI function)	USPL	LSPL	0	Level 1	SET2.1
SV2		Second set value (only available in DI function)	USPL	LSPL	0	Level 1	SET2.1
SV3		Third set value (only available in DI function)	USPL	LSPL	0	Level 1	SET2.2
SV4		Fourth set value (only available in DI function)	USPL	LSPL	0	Level 1	SET2.2

DI Mode table

Mode	Function Description	
OFF	D1SL=OFF	D2SL=OFF
	Disable Loop1 digital input function	Disable Loop2 digital input function
SWSV	D1SL= SWSV SV=SV1~SV4 Please refer to SV Switch table	D2SL= SWSV
	※ If D1SL is set to SWSV, Please set D2SL to OFF ※ If D2SL is set to SWSV, Please set D1SL to OFF	
R_S	D1SL= R_S Switch loop1 RUN/STOP ON 	D2SL= R_S Switch loop2 RUN/STOP ON 
A_M	D1SL= A_M Switch loop1 AUTO/MMAN ON 	D2SL= A_M Switch loop2 AUTO/MMAN ON 
AT	D1SL= AT Switch loop1 autotuning ON/OFF ON 	D2SL= AT Switch loop2 autotuning ON/OFF ON 
RESV	D1SL= RESV Switch loop1 SV to Local SV or Remote SV ON 	D2SL= AT Switch loop2 autotuning ON/OFF ON 
	※ D2SL should be set as OFF or other modes	
AOEN	D1SL= AOEN Switch Retransmission ON/OFF ON 	D2SL= AOEN Switch Retransmission ON/OFF ON 
	※ If D2SL is set to AOEN, Please set D1SL to OFF or other modes	※ If D1SL is set to AOEN, Please set D2SL to OFF or other modes
TIM	D1SL= TIM Switch loop1 timer ON/OFF ON 	D2SL= TIM Switch loop2 timer ON/OFF ON 

Mode	Function Description					
CNT	D1SL= CNT	D2SL= OFF				
	<p>ON OFF</p> <p>Count function = OFF Count function = ON</p> <p>Counter = 1 = 2 = 3.....</p> <p>DI2</p>					
	<p>* DISL= CNT(counter mode), D2SL is automatically set to OFF</p>					
PROG	<p>D1SL= PROG</p> <table border="1"> <thead> <tr> <th>Program execute</th> <th>Program stop</th> </tr> </thead> <tbody> <tr> <td> <p>ON OFF</p> <p>100ms</p> <p>Program=RUN</p> </td> <td> <p>ON OFF</p> <p>100ms</p> <p>Program=RESET</p> </td> </tr> </tbody> </table>		Program execute	Program stop	<p>ON OFF</p> <p>100ms</p> <p>Program=RUN</p>	<p>ON OFF</p> <p>100ms</p> <p>Program=RESET</p>
Program execute	Program stop					
<p>ON OFF</p> <p>100ms</p> <p>Program=RUN</p>	<p>ON OFF</p> <p>100ms</p> <p>Program=RESET</p>					
	<p>* In the PROG mode, please use a push button in DI1 switch</p>					


SV Switch table

Mode	DI2	DI1	Function Description
SWSV	0	0	SV=SV1
			<p>DI1 OFF</p> <p>DI2 OFF</p>
	0	1	SV=SV2
			<p>DI1 OFF</p> <p>DI2 ON</p>
SWSV	1	0	SV=SV3
			<p>DI1 OFF</p> <p>DI2 ON</p>
SWSV	1	1	SV=SV4
			<p>DI1 ON</p> <p>DI2 OFF</p>

Example

1. Use two sets of DI to switch 4 sets of SV

Assuming Local SV=0, set SV1=100, SV2=200, SV3=150, SV4=250
 After the power is turned on, DI1=OFF, DI2=OFF, Local SV=100(SV1)
 When DI1=ON, DI2=OFF, local SV=200(SV2)
 When DI1=OFF, DI2=ON, local SV=150(SV3)
 When DI1=ON, DI2=ON, local SV=250(SV4)



Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SET2.1	1	Display parameter SV1, SV2
1	4	SET2.2	1	Display parameter SV3, SV4
1	4	SETD.3	1	Display parameter D1SL, D2SL
---	5	D1SL	SWSV	Switch LOOP1 SV1-SV4
---	5	D2SL	OFF	---

2. Switch DI1 of loop1 with DI1 = RUN/STOP

Set D1SL = R_S, the controller will be in RUN mode after turning on DI1(ON) the controller will be in STOP mode after turning off DI1(OFF)

Parameter Setting

LOOP	Level	Parameter	Set value	Description
---	5	D1SL	R_S	DI1=ON R_S= RUN DI1=OFF R_S= STOP

3. Switch DI2 of loop2 with DI2 = RUN/STOP

Set D2SL = R_S, the controller will be in RUN mode after turning on DI2(ON) the controller will be in STOP mode after turning off DI2(OFF)

Parameter Setting

LOOP	Level	Parameter	Set value	Description
---	5	D2SL	R_S	DI2=ON R_S= RUN DI2=OFF R_S= STOP

4. Start/stop loop 1 timer with DI1

Set D1SL = TIM, TIM = 05.00 (5 minutes) the controller will start timing when DI1 is connected, and alarm 1 moves when the timer value reaches 5 minutes.

After disconnection of DI1, alarm 1 is released and the timer value is cleared

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SET2.3	1	Display parameter TIM
1	1	TIM	05.00	Timer for 5 minutes
1	3	ALD1	TIM	When timer is up, alarm activates
---	5	D1SL	TIM	DI1 activates/ stop timer

5. Use DI as a counter to count the external contact or pulse signal. When the count reaches 100, the alarm 1 activates.

Set D1SL=TIM, CNT=100, the controller will start the counting function when DI1 is connected, the external contact or pulse signal is connected to DI2, when the count value reaches 100 times

Alarm 1 activates, alarm 1 is released after DI1 is disconnected, count value is cleared

Parameter Setting


LOOP	Level	Parameter	Set value	Description
1	4	SET2.4	1	Display parameter CNT
1	1	CNT	100	Target counter value of 100
1	3	ALD1	CNT	Alarm activated, once counter value is reached
---	5	D1SL	CNT	DI1 Activate counter/ DI2 used for counter value
---	5	D2SL	OFF	As D1SL=CNT, D2SL is forced to be OFF

11.7 Dehumidification Function

Description

The WT controller provides dehumidification to protect the heater. When the power is turned on, the heater is dehumidified with low power. When the dehumidification is completed, the normal power is output to the heater.

Function Diagram



The related parameter of Dehumidification Function are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
RH.TC		Dehumidification temperature If PV less than RH.TC manipulated value = RH.PO	200.0	0.0	125.0	Level 4	SETC.3
RH.PO		Dehumidification manipulated value 0 : OFF disable dehumidification function Other values : 0.1~100.0 manipulated value	100.0	OFF	OFF	Level 4	SETC.3
RH.TM		Dehumidification time time format : min.sec	COTI	00.00	15.00	Level 4	SETC.3

Example description

After the controller is turned on, when the PV does not reach 50°C, manipulated value fixed in 20%. When the time exceeds 15 minutes or the PV is greater than 50°C, the controller will produce output of normal PID gain.


Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SETC.3	1	Display parameter RH.TC, RH.PO, RH.TM
1	1	SV	100.0	Target temperature
1	4	RH.TC	50.0	Execute de-humidifying function when PV is lower than this temperature
1	4	RH.PO	20.0	When executing dehumidification function the manipulated value fixed in 20%
1	4	RH.TM	15.00	Max dehumidification function time

11.8 24-Hour Timer

Description


The WT controller provides a 24-hour timer to start/stop when a timer value arrives, or to switch SV Function Diagram



The related parameter of 24-Hour Timer are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
CUTM		24 hour timer Current time	23.59	00.00	0	Level 1	SET3.1
ONTM		24 hour timer, ON time PV address use for display current time, SV address use for setting ON time	23.59	00.00	0	Level 1	SET3.1
OFTM		24 hour timer, OFF time PV address use for display current time, SV address use for setting OFF time	23.59	00.00	0	Level 1	SET3.1
TMSL		24 hour timer, mode selection 0 : OFF (24 hour timer function disable) 1 : SWSV (switch SV) 2 : R_S (switch RUN/STOP) 3 : R_SO (switch to run)	R_SO	OFF	OFF	Level 4	SETC.1

Flow Setting



Example

1. The parameter R_S switches to the RUN at 8:30 a.m. and activate the alarm1 at the same time, the parameter switches to STOP at 17:30 p.m.

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SET3.1	1	Display parameter CUTM ONTM OFTM
1	4	SETC.1	1	Display parameter TMSL
1	1	CUTM	---	Setting this parameter according to Greenwich Mean Time(GMT)
1	1	ONTM	08.30	Switch to RUN status at 8:30 a.m.
1	1	OFTM	17.30	Switch to STOP status at 17:30 p.m.
1	3	ALD1	CUTM	Switch to RUN status and activate alarm at the same time
1	4	TMSL	R_S	Switch to RUN/STOP

2. Switch the parameter R_S to RUN at 8:30 a.m. and activate the alarm1

Parameter Setting

LOOP	Level	Parameter	Set value	Description
1	4	SET3.1	1	Display parameter CUTM ONTM OFTM
1	4	SETC.1	1	Display parameter TMSL
1	1	CUTM	---	Setting this parameter according to Greenwich Mean Time(GMT)
1	1	ONTM	08.30	Switch to RUN status at 8:30 a.m.
1	3	ALD1	CUTM	Switch to RUN status and activate alarm 1 at the same time
1	4	TMSL	R_S	Switch to RUN/STOP

3. After controller boot completed the local SV=SV2, local SV switches to SV1 at 10:30 a.m., and local SV switches to SV2 at 1:30 p.m.

Parameter Setting


LOOP	Level	Parameter	Set value	Description
1	4	SET3.1	1	Display parameter CUTM ONTM OFTM
1	4	SETC.1	1	Display parameter TMSL
1	4	SET2.1	1	Display parameter SV1 SV2
1	1	CUTM	---	Setting this parameter according to Greenwich Mean Time(GMT)
1	1	ONTM	10.30	Switch SV=SV1 at 10:30 a.m.
1	1	OFTM	13.30	Switch SV=SV2 at 01:30 p.m.
1	4	TMSL	SWSV	Switch SV

11.9 Motor Valve Control

Description

WT motor valve control function converts the control output value of the controller into the corresponding signal to control a motor driven valve and then performs temperature control of a controlled object by regulating fluid flow.

Function Diagram



Description of function

When the feedback resistance is provided

1. Adjusting valve position automatically
2. The valve position can be manually changed.
3. Force the controller to switch to no feedback resistance control mode when feedback resistance input breaks
4. High/Low limit of valve position can be set.


When the feedback resistance is not provided:

1. Control motor operation can be restricted by the parameter "OUTL".
2. The UP/DOWN key is used to output opening or closing signal in manual mode
 - UP key(open-side) : While the UP key is being pressed, open-side output (OUT1) is output continuously.
Releasing the UP key turns off the output on the open-side to hold the opened state at that time.
 - DOWN key(close-side) : While the DOWN key is being pressed, close-side output (OUT2) is output continuously.
Releasing the DOWN key turns off the output on the closed-side to hold the opened state at that time.

The related parameter of motor valve control function are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
PV2	---	Valve opening monitor	100.0	0.0	---	Level 1	---
OU.TY		Hardware drive selection 0 : SING (single output) 1 : DOUB (dual output) 2 : 1SCR (single phase control) 3 : HLSL (high low signal selection) 4 : FBMV (valve control with feedback) 5 : NFMV (valve control without feedback)	5	0	0	Level 4	SETB.1
PMAC		Automatic valve position adjustment 0 : OFF stop automatic adjust 1 : ON start automatic adjust 2 : E_PB Valve position determined by external button	E_PB	OFF	OFF	Fast	OU.TY = FBMV
MVRT		Motor valve traveling time Time unit : second	150	5	5	Fast	OU.TY = FBMV & SETC.2=1
CYT1		Motor valve action interval time. Time unit : second	10	1	5	Fast	OU.TY = FBMV or OU.TY = NFMV
HYSM		Motor valve action main adjustment unit : percentage	5.0	0.0	1.0	Fast	OU.TY = FBMV & SETC.2=1
HYS1		Motor valve action sub adjustment unit : percentage	HYSM	0.0	0.5	Fast	OU.TY = FBMV or OU.TY = NFMV

Motor valve Initial Setting



1. Executing automatic valve position adjustment

Parameter	Symbol	Content	Default	Level
PMAC		Automatic valve position adjustment 0 : OFF stop automatic adjust 1 : ON start automatic adjust 2 : E_PB Valve position determined by external button	OFF	Fast

The motor valve low position(AN.LO) and high position(AN.HI) are calibrated and the travel time from completely open to completely closed is set automatically

When the measurement has been complete the setting of the parameter will change to OFF."PMER" will be display if any of following errors occurs during execution.If an error occur check the wiring and other factors and execute automatic valve position adjustment again.

2. Setting motor valve traveling time

Parameter	Symbol	Content	Default	Level
MVRT		Motor valve traveling time Time unit : second	5	Fast

With feedback resistance mode

Executing automatic valve position adjustment will get MVRT setting value automatically

Without feedback resistance mode

Check the motor valve specification and setting the MVRT value of a manually

3. Setting valve action interval time

Parameter	Symbol	Content	Default	Level
CYT1		Motor valve action interval time. Time unit : second	5	Fast

EX1 : Setting CYT1=5, after executing current valve action, If the controller calculates that the valve needs to be closed for 2 seconds, controller will delay 5 seconds before performing close valve action

EX2 : Setting CYT1=7, after executing current valve action, If the controller calculates that the valve needs to be open for 2 seconds, controller will delay 7 seconds before performing open valve action

4. Setting motor valve action main adjustment

Parameter	Symbol	Content	Default	Level
HYSM		motor valve action main adjustment unit : percentage	1.0	Fast

When error% accumulates to the set value of HYSM the controller will drive motor valve to eliminate this error%

EX1 : set HYSM =0.5, when error% accumulates to 0.5 the controller will drive motor valve to eliminate this error%

EX2 : set HYSM =1.0, when error% accumulates to 1.0 the controller will drive motor valve to eliminate this error%

The smaller the set value of this parameter, the more frequent the valve action, the more precise the control, but it will also affect the valve life, proper HYSM setting reduces valve operating frequency to protect valve life

5. Setting motor valve action sub adjustment

Parameter	Symbol	Content	Default	Level
HYS1		motor valve action sub adjustment unit : percentage	0.5	Fast

When the error% accumulates to the set value of HYSM, the controller will drive the valve to eliminate the set value of HYS1

EX1 : set HYSM =0.5, HYS1 =0.3, when error% accumulates to 0.5% the controller will drive motor valve to eliminate 0.3%

EX2 : set HYSM =1.0 , HYS1 =0.5, when error% accumulates to 1.0% the controller will drive motor valve to eliminate 0.5%

6. Setting motor valve high/low limit in resistance feedback control mode


Parameter	Symbol	Content	Default	Level
MOLL		low limit of valve position	0.0	Fast
MOLH		high limit of valve position	100.0	Fast

EX1 : if you want set 20% low limit of valve position, setting MOLL=20.0

EX2 : if you want set 80% high limit of valve position, setting MOLH=80.0

Notes

1. The lowest valve position and the highest valve position are automatically written into AN.LO (LOOP2) & AN.HI (LOOP2) after executing automatic valve position adjustment.
2. When performing automatic valve position adjustment (PMAC=ON), please make sure that the fuel is closed.
3. When the controller detects that the feedback resistance is disconnected, it will automatically switch to no feedback control mode (OU.TY=NFBMV) and PV area show "PMER" message.
4. It is recommended to install spark killer at close side and open side of valve.



11.10 Piece Linear Compensation


Description

When the analog input signal source is nonlinear, using piece linear compensation method to compensate this signal, make it linearity

The related parameter of piece linear compensation are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
MLNB		Piece linear compensation segment select TRIP : leave setting loop 1~10 : segment select	10	TRIP	TRIP	Level 3	SETA.3
COMP		Piece linear compare value	USPL	LSPL	LSPL	Level 3	SETA.3
OFFS		Piece linear offset value	150.0	-150.0	0.0	Level 3	SETA.3
SETA.3		0 : MLNB, COMP, OFFS hide 1 : MLNB, COMP, OFFS display	1	0	0	Level 4	---
SETF.4		0 : Disable piece linear compensation 1 : Enable piece linear compensation	1	0	0	Level 5	SETF.4

Edit flow-chat



Set MLNB

Parameter	LED display	Description	Default	Level
MLNB		Piece linear compensation segment select TRIP : leave setting loop 1~10 : segment select	TRIP	Level 3

When $MLNB \neq TRIP$ the display loop in MLNB → COMP → OFFS

When $MLNB=TRIP$ leave piece linear compensation parameter loop

Set COMP

Parameter	LED display	Description	Default	Level
COMP		Piece linear compensation compare value	LSPL	Level 3

When non-linear signal value within the set value of COMP, it needs to be compensated.

First COMP set value=LSPL

Last COMP set value=USPL


Set OFFS

Parameter	LED display	Description	Default	Level
OFFS		Piece linear compensation offset value	0.0	Level 3

When non-linear signal value within the set value of COMP, OFFS use for increase or decrease original non-linear signal

Before the function starts

Piece Linear Compensation



Example1:

Assume signal source is a nonlinear signal within 320 °C, and the controller is set to correct at three temperature points.

- (1) When the temperature is 95°C, it needs to be corrected by +5°C.
- (2) When the temperature is 185°C, it needs to be corrected by +15°C.
- (3) When the temperature is 320°C, it needs to be corrected by +30°C.

Step 1: Set SETA.3=1 and SETF.4=0

Step 2: Set MLNB = 1, COMP = LSPL, OFFS = 0

Step 3: set MLNB = 2, COMP = 95, OFFS = 5

Step 4: Set MLNB = 3, COMP = 185, OFFS = 15


Step 5: Set MLNB = 4, COMP = 320, OFFS = 30

Step 6: Set MLNB = 5, COMP = USPL, OFFS = 0

Step 7: Set MLNB = TRIP and SETF.4=1

Example2:

Input signal 4~20mA, range 0~5000, the input signal is nonlinear (as shown in the figure below), use 10 points piece linear compensation.



11.11 RAMP & SOAK

Description

The WT series controller provides a single ramp and soak function, after booting completed, the SV starts to increase according to the set value of RAMP. When the soak condition is met the SOAK function will be executed according to the set value of SOAK, and driving the output and alarm to ON or OFF after the SOAK time is executed finish.

The related parameter of ramp and soak function are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
RAMP		The rate of change during SV ramp operation format : °C / minute	99.99	-19.99	0.00	Level 1	SV.TY=RAMP & SETE.4
SOAK		Soak time Time format : min.sec	COTI	0.00	0.10	Level 1	ALDX=MSOK ALDX=SOAK ALDX=FSOK

※ X=1 / 2 / 3

Parameter	Set value	Symbol	Content
ALDX	MSOK		Boot completed, the alarm is ON. When PV ≥ target SV start the soak timer, alarm and control function are turned OFF in soak time finish
	SOAK		Boot completed, the alarm is ON (1) RAMP SV reach target SV (2) PV ≥ target SV When both of the above conditions are true start the soak timer, alarm and control function are turned OFF in soak time finish (in this function ramp function is necessary)
	FSOK		Boot completed, the alarm is OFF. when PV ≥ target SV start the soak timer, alarm is turned ON and the control function keep ON in soak time finish

※ X=1 / 2 / 3

Example (1) RAMP+SOAK

Boot completed, the alarm is ON, target SV=100.0, SV rising 5.00°C per minute


(1) RAMP SV reach 100.0

(2) PV ≥ 100.0

When both of the above conditions are true start the soak timer, alarm and parameter R_S are turned OFF in soak time finish

Parameter setting

LOOP	Level	Parameter	Set value	Description
1	1	SV	100.0	target SV
1	1	R_S	RUN	enable control and alarm function
1	1	RAMP	5.00	rising 5.00°C per minute
1	1	SOAK	10.00	soak time=10 minutes
1	3	ALD1	SOAK	alarm1 as soak alarm
1	4	SV.TY	RAMP	SV source RAMP function
1	4	SETE.4	1	display RAMP



Change SV to re-execute RAMP/SOAK function

1. Parameter R_S display in LEVEL_1

After change SV, set parameter R_S=RUN, controller will re-execute RAMP/SOAK function

2. Parameter R_S hide in LEVEL_1

After change SV, controller will re-execute RAMP/SOAK function automatically


Example (2) RAMP+MSOK

Boot completed, the alarm is ON, target SV=100.0, SV rising 5.00°C per minute

When PV \geq 100.0 start the soak timer, alarm and parameter R_S are turned OFF in soak time finish.

Parameter setting

LOOP	Level	Parameter	Set value	Description
1	1	SV	100.0	target SV
1	1	R_S	RUN	enable control and alarm function
1	1	RAMP	5.00	rising 5.00°C per minute
1	1	SOAK	10.00	soak time=10 minutes
1	3	ALD1	MSOK	alarm1 as soak alarm
1	4	SV.TY	RAMP	SV source RAMP function
1	4	SETE.4	1	display RAMP



Change SV to re-execute RAMP/SOAK function

1. Parameter R_S display in LEVEL_1

After change SV, set parameter R_S=RUN, controller will re-execute RAMP/SOAK function

2. Parameter R_S hide in LEVEL_1

After change SV, controller will re-execute RAMP/SOAK function automatically


Example (3) RAMP+FSOK

Boot completed, the alarm is OFF, target SV=100.0, SV rising 5.00°C per minute

When PV \geq 100.0 start the soak timer, alarm is turned ON and parameter R_S keep RUN state in soak time finish

Parameter setting

LOOP	Level	Parameter	Set value	Description
1	1	SV	100.0	target SV
1	1	R_S	RUN	enable control and alarm function
1	1	RAMP	5.00	rising 5.00°C per minute
1	1	SOAK	10.00	soak time=10 minutes
1	3	ALD1	FSOK	alarm1 as soak alarm
1	4	SV.TY	RAMP	SV source RAMP function
1	4	SETE.4	1	display RAMP




Example (4) use only MSOK

Boot completed, the alarm is ON, target SV=100.0, control PV to 100.0 directly

When PV \geq 100.0 start the soak timer, alarm and parameter R_S are turned OFF in soak time finish

Parameter setting

LOOP	Level	Parameter	Set value	Description
1	1	SV	100.0	target SV
1	1	R_S	RUN	enable control and alarm function
1	1	SOAK	10.00	soak time=10 minutes
1	3	ALD1	MSOK	alarm1 as soak alarm
1	4	SV.TY	FIX	SV change by keypad



Change SV to re-execute RAMP/SOAK function

1. Parameter R_S display in LEVEL_1

After change SV, set parameter R_S=RUN, controller will re-execute RAMP/SOAK function

2. Parameter R_S hide in LEVEL_1

After change SV, controller will re-execute RAMP/SOAK function automatically


Example (5) use only FSOK

Boot completed, the alarm is OFF,target SV=100.0, control PV to 100.0 directly

When PV \geq 100.0 start the soak timer, alarm is turned ON and parameter R_S keep RUN state in soak time finish

Parameter setting

LOOP	Level	Parameter	Set value	Description
1	1	SV	100.0	target SV
1	1	R_S	RUN	enable control and alarm function
1	1	SOAK	10.00	soak time=10 minutes
1	3	ALD1	FSOK	alarm1 as soak alarm
1	4	SV.TY	FIX	SV change by keypad



11.12 Password

Description

The WT series controller provides a password function to inhibit operator enter Level 3~5.

The related parameter of password function are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
PW	8888	Password input value	9999	0	0	Level 1	SET2.4 (loop2)
MPW	---	Verification code setting value This parameter can only be modified by communication address : 1022 0 : No password protection ,user can enter Level 3~5 according to the value of LOCK others : When password input value and verification code are the same, user can enter Level 3~5 according to the value of LOCK. otherwise, user cannot enter Level 3~5.	9999	0	0	---	---

example

Set verification code=1234 via communication

1. input 1234 in the parameter PW, allow enter Level_1~3
2. input 5678 in the parameter PW, inhibit enter Level_1~3

There is a limit on the number of input passwords, after more than 3 times, it will be locked and cannot be entered.

If user want to unlock please contact factory or distributor.

Parameter setting

LOOP	Level	Parameter	Set value	Description
2	1	PW	1234	password input value
---	---	MPW	1234	verification code, modify via communication

Notes


1. The value of the verification code can only be modified through communication
2. Password input value(PW) in LOOP2, to password input, please set parameter LOOP to LOP2 first
3. There is a limit on the number of password input ,please remember the value of verification code

11.13 Proportional Control

Description

Proportional control is one of the simplest ways to control method, controller manipulated value proportional to input error signal, this chapter explains how to set related parameters.

Function Diagram



The related parameter of proportional control are as below:


Parameter	Symbol	Content	Range		Default	Level	Hide/ Display
			MAX	MIN			
SV	---	Set value	USPL	LSPL	---	Level 1	---
P1		Main output proportional band 0.0 : ON/OFF control Other values : proportional band setting value	200.0	0.0	3.0	Level 2	---
OUTM		Control action selection 0 : HEAT reverse action 1 : COOL direct action	COOL	HEAT	HEAT	Level 3	SET9.4

Setting step

1. Select control action
2. Determine the proportional band
3. Calculate symmetry value, symmetry value = (proportional band maximum - proportional band minimum) / 2
4. Set SV, SV = Midpoint of proportional band
5. Full range = (Range maximum – range minimum)
6. Calculate Error% = (symmetry value / Full range) x 100
7. Calculate P = (Error% x 2)

Example 1 :


INPT = K1(-50.0~600.0) when PV in the range of 90.0 ~ 100.0 output proportional(decrease) SV= ? P= ?



1. OUTM = HEAT(Reverse)
2. Proportional band → 90.0~100.0
3. Symmetry value = (proportional band maximum - proportional band minimum) / 2 → (100.0 - 90.0) / 2 = 5.0
4. SV = Midpoint of proportional band → SV=95.0
5. Full range = (Range maximum – range minimum) → 600.0 - (-50.0) = 650.0
6. Error% = (Symmetry value / Full range) x 100 → (5.0 / 650.0) x 100 = 0.76923
7. P= (Error% x 2) → 0.76923 x 2 = 1.5384(approx 1.5)

Example 2 :

INPT= AN4(0.0~100.0) when PV in the range of 0.0 ~ 100.0 output proportional(increase) SV= ? P= ?



1. OUTM = COOL(Direct)
2. Proportional band → 0.0~100.0
3. Symmetry value = (proportional band maximum - proportional band minimum) / 2 → (100.0 - 0.0) / 2 = 50.0
4. SV = Midpoint of proportional band → SV=50.0
5. Full range = (Range maximum – range minimum) → 100.0 - 0.0 =100.0
6. Error% = (Symmetry value / Full range) x 100 → (50.0 / 100.0) x 100 = 50.0
7. P= (Error% x 2) → 50.0 x 2 =100.0

Notes


1. When using proportional control I1 and D1 must be set to 0
2. Full range please check Chapter 4 "Input Range Table"
3. Only using proportional control will eventually have a steady state error

11.14 Master-Slave Communication

Description

Transmission master controller SV to slave controller SV, all slave controller SV can be consistent

Wiring



The related parameter of master-slave communication are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/ Display
			MAX	MIN			
RATE	<i>Rate</i>	Slave SV rate RATE SV = SV x (RATE/9999)	9999	0	9999	Level 1	SET2.1 & SET0.2
PRTO	<i>Prto</i>	Protocol selection 0 : Shihlin Electric 1 : MRTU (Please refer to communication manual)	RTU	Shihlin Electric	Shihlin Elect	Level 3	SET5.4
FOMA	<i>Foma</i>	Data format 0 : O_81 (parity bit=odd, stop bit=1) 1 : O_82 (parity bit=odd, stop bit=2) 2 : E_81 (parity bit=even, stop bit=1) 3 : E_82 (parity bit=even, stop bit=2) 4 : N_81 (parity bit=none, stop bit=1) 5 : N_82 (parity bit=none, stop bit=2)	N_82	O_81	O_81	Level 3	SET5.4
IDNO	<i>Idno</i>	Controller station	254	0	1	Level 3	SET5.4
BAUD	<i>Baud</i>	Baud rate 0 : 24(2400) 1 : 48(4800) 2 : 96(9600) 3 : 192(19200) 4 : 384(38400) 5 : 576(57600) 6 : 1152(115200) bps	1152	24	96	Level 3	SET5.4

Master controller setting step

- Master controller setting step
1. IDNO= 0, PRTO= Shihlin Electric
2. FOMA= O_81, BAUD= 96
3. After completing the above steps, master controller start to transmit SV to slave controller SV

Slave controller setting step

- Slave controller setting step

 1. IDNO= 1, PRTO= Shihlin Electric
 2. FOMA= O_81, BAUD= 96
 3. RATE= 9999
 4. After completing the above steps, slave controller start to receive master controller SV

Notes

- Notes

 - After adding master-slave communication, RS-485 communication not available
 - Master-slave communication only available in Shihlin Electric protocol (PRTO= Shihlin Electric)
 - Master controller does not use parameter RATE, to attenuate the SV received by slave controller just adjust parameter RATE
 - Master controller can connect up to 10 slave controllers, and the wiring between every controller should not exceed 1 meter.


12. Alarm Action

Description

The WT controller can support up to three sets of alarm functions. Each set of alarms has 20 mode, except NONE, MSOK, and SOAK.

There are 6 active options for each mode. There are a total of more than 100 operating modes to choose. Users can choose the most suitable alarm mode according to their needs for system protection or application.

Function Diagram



The related parameter of alarm function are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
R_S		RUN/STOP mode selection 0 : STOP (output & alarm disable) 1 : RUN (output & alarm enable)	RUN	STOP	RUN	Level 1	SET3.4
AL1H		Alarm1 upper set value (ALD1 = DE.HI / DE.HL / BA.ND / PR.HI / DEHI / DEHL / BAND / PRHI appear)	USPL	LSPL	1.0	Level 1	SET1.2
AL1L		Alarm1 lower set value (ALD1 = DE.LO / DE.HL / BA.ND / PR.LO / DELO / DEHL / BAND / PRLO appear)	USPL	LSPL	1.0	Level 1	SET1.2
AL2H		Alarm2 upper set value (ALD2 = DE.HI / DE.HL / BA.ND / PR.HI / DEHI / DEHL / BAND / PRHI appear)	USPL	LSPL	1.0	Level 1	SET1.3
AL2L		Alarm2 lower set value (ALD2 = DE.LO / DE.HL / BA.ND / PR.LO / DELO / DEHL / BAND / PRLO appear)	USPL	LSPL	1.0	Level 1	SET1.3
AL3H		Alarm3 upper set value (ALD3 = DE.HI / DE.HL / BA.ND / PR.HI / DEHI / DEHL / BAND / PRHI appear)	USPL	LSPL	1.0	Level 1	SET1.4
AL3L		Alarm3 lower set value (ALD3 = DE.LO / DE.HL / BA.ND / PR.LO / DELO / DEHL / BAND / PRLO appear)	USPL	LSPL	1.0	Level 1	SET1.4
ALD1		Alarm1 mode selection (Please refer to Chapter 12.1 Alarm Mode)	FSOK	NONE	DEHI	Level 3	SET7.4
ALT1		FLIK (00.00) : Flicker COTI (99.59) : Continued ON 00.01~99.58 : delay time	COTI	FLIK	COTI	Level 3	SET7.4
HYA1		Hysteresis setting for alarm1	100.0	-100.0	1.0	Level 3	SET7.4
SEA1		Alarm1 special function setting (Please refer to Chapter 12.2 Alarm Special Setting)	1111	0000	0000	Level 3	SET7.4
ALD2		Alarm2 mode selection (Please refer to Chapter 12.1 Alarm Mode)	FSOK	NONE	NONE	Level 3	SET8.1
ALT2		FLIK (00.00) : Flicker COTI (99.59) : Continued ON 00.01~99.58 : delay time	COTI	FLIK	COTI	Level 3	SET8.1
HYA2		Hysteresis setting for alarm 2	100.0	-100.0	1.0	Level 3	SET8.1
SEA2		Alarm2 special function setting (Please refer to Chapter 12.2 Alarm Special Setting)	1111	0000	0000	Level 3	SET8.1

The related parameter of alarm function are as below:

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
ALD3	R083	Alarm3 mode selection (Please refer to Chapter 12.1 Alarm Mode)	FSOK	NONE	NONE	Level 3	SET8.2
ALT3	R083	FLIK (00.00) : Flicker COTI (99.59) : Continued ON 00.01~99.58 : delay time	COTI	FLIK	COTI	Level 3	SET8.2
HYA3	HYA3	Hysteresis setting for alarm 3	100.0	-100.0	1.0	Level 3	SET8.2
SEA3	SEA3	Alarm3 special function setting (Please refer to Chapter 12.2 Alarm Special Setting)	1111	0000	0000	Level 3	SET8.2

12.1 Alarm Mode

: SV : Alarm set value X : 1 / 2 / 3 (There are up to 3 sets of alarms)

ALDX		Index value	Alarm mode	Description
NONE		0	No alarm function	Not drive any alarm relays and the corresponding LED lamp.
DE.HI		1	Deviation high (With hold action)	
				Formula : $PV \geq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV \leq (SV + ALXH - HYAX) \rightarrow \text{Alarm OFF}$
DE.LO		2	Deviation low (With hold action)	
				Formula : $PV \leq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV \geq (SV + ALXL + HYAX) \rightarrow \text{Alarm OFF}$
DE.HL		3	Deviation high/low (With hold action)	
				Formula : $PV \leq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV \geq (SV + ALXL + HYAX) \rightarrow \text{Alarm OFF}$ $PV \geq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV \leq (SV + ALXH - HYAX) \rightarrow \text{Alarm OFF}$
BA.ND		4	Band (With hold action)	
				Formula : $PV \leq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV > (SV + ALXH) \rightarrow \text{Alarm OFF}$ $PV \geq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV < (SV + ALXL) \rightarrow \text{Alarm OFF}$
PR.HI		5	Process high (With hold action)	
				Formula : $PV \geq ALXH \rightarrow \text{Alarm ON}$ $PV \leq (ALXH - HYAX) \rightarrow \text{Alarm OFF}$
PR.LO		6	Process low (With hold action)	
				Formula : $PV \leq ALXL \rightarrow \text{Alarm ON}$ $PV \geq (ALXL + HYAX) \rightarrow \text{Alarm OFF}$
PEND		7	Program end	When the program is end, the alarm action This mode only available in program type controller
SYAB		8	System error	The alert action, when PV displays error message
HBA		9	HBA (Heater Break Alarm)	Activated conditions : 1. Heater current(HBCU) is less the HBSV set value 2. OUT1 manipulated value exceed HBOP set value 3. Fit with Condition1 and 2 and exceed set the seconds of HBTM

Hold Action

There is a dot on the led display for alarm hold action, such as → (Deviation high with hold action)

When the controller boot completed, the PV is within the alarm range, and no alarm action will be generated at this time, until the PV exceed alarm range then enter the alarm range again the alarm will be activated.

12.1 Alarm Mode

▲ : SV **△** : Alarm set value **X** : 1 / 2 / 3 (There are up to 3 sets of alarms)


ALDX		Index value	Alarm mode	Description
MSOK		10	soak timer	Boot completed, the alarm is ON. When PV ≥ target SV start the soak timer, alarm and control function are turned OFF in soak time finish please refer to chapter 11.11 RAMP + SOAK
DEHI		11	Deviation high	
				<table border="1"> <tr> <td>Formula</td> <td>$PV \geq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV \leq (SV + ALXH - HYAX) \rightarrow \text{Alarm OFF}$</td> </tr> </table>
Formula	$PV \geq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV \leq (SV + ALXH - HYAX) \rightarrow \text{Alarm OFF}$			
DELO		12	Deviation low	
				<table border="1"> <tr> <td>Formula</td> <td>$PV \leq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV \geq (SV + ALXL + HYAX) \rightarrow \text{Alarm OFF}$</td> </tr> </table>
Formula	$PV \leq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV \geq (SV + ALXL + HYAX) \rightarrow \text{Alarm OFF}$			
DEHL		13	Deviation high/low	
				<table border="1"> <tr> <td>Formula</td> <td>$PV \leq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV \geq (SV + ALXL + HYAX) \rightarrow \text{Alarm OFF}$ $PV \geq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV \leq (SV + ALXH - HYAX) \rightarrow \text{Alarm OFF}$</td> </tr> </table>
Formula	$PV \leq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV \geq (SV + ALXL + HYAX) \rightarrow \text{Alarm OFF}$ $PV \geq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV \leq (SV + ALXH - HYAX) \rightarrow \text{Alarm OFF}$			
BAND		14	Band	
				<table border="1"> <tr> <td>Formula</td> <td>$PV \leq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV > (SV + ALXH) \rightarrow \text{Alarm OFF}$ $PV \geq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV < (SV + ALXL) \rightarrow \text{Alarm OFF}$</td> </tr> </table>
Formula	$PV \leq (SV + ALXH) \rightarrow \text{Alarm ON}$ $PV > (SV + ALXH) \rightarrow \text{Alarm OFF}$ $PV \geq (SV + ALXL) \rightarrow \text{Alarm ON}$ $PV < (SV + ALXL) \rightarrow \text{Alarm OFF}$			
PRHI		15	Process high	
				<table border="1"> <tr> <td>Formula</td> <td>$PV \geq ALXH \rightarrow \text{Alarm ON}$ $PV \leq (ALXH - HYAX) \rightarrow \text{Alarm OFF}$</td> </tr> </table>
Formula	$PV \geq ALXH \rightarrow \text{Alarm ON}$ $PV \leq (ALXH - HYAX) \rightarrow \text{Alarm OFF}$			
PRLO		16	Process low	
				<table border="1"> <tr> <td>Formula</td> <td>$PV \leq ALXL \rightarrow \text{Alarm ON}$ $PV \geq (ALXL + HYAX) \rightarrow \text{Alarm OFF}$</td> </tr> </table>
Formula	$PV \leq ALXL \rightarrow \text{Alarm ON}$ $PV \geq (ALXL + HYAX) \rightarrow \text{Alarm OFF}$			
PRUN		17	Program run	When the program is being executed, the alarm action *This mode only available in program type controller
SYNO		18	System normal	The Alert action, when PV normal displays(no error message)
SOAK		19	Ramp Soak Timer	Boot completed, the alarm is ON 1. RAMP SV reach target SV 2. PV ≥ target SV When both of the above conditions are true start the soak timer, alarm and control function are turned OFF in soak time finish (in this function ramp function is necessary) please refer to chapter 11.11 RAMP + SOAK

12.1 Alarm Mode

: SV : Alarm set value X : 1 / 2 / 3 (There are up to 3 sets of alarms)




ALDX		Index value	Alarm mode	Description
TIM		20	Timer	Alarm action in time up *This mode only available in Digital Input function
CNT		21	Counter	Alarm action after counter value is reached *This mode only available in Digital Input function
CUTM		22	24H Timer	When CUTM = ONTM, alarm activates When CUTM = OFTM, alarm stops
FSOK		23	soak timer	Boot completed, the alarm is OFF. when PV ≥ target SV start the soak timer, alarm is turned ON and the control function keep ON in soak time finish please refer to chapter 11.11 RAMP + SOAK

12.2 Alarm Special Setting




※ : Alarm Special Setting SEA1~SEA3

X : 1 / 2 / 3 (There are up to 3 sets of alarms)


SEAX	Status = 0	Status = 1
SEAX.1	Alarm relay action in A contact (Normal Open)	Alarm relay action in B contact (Normal Close)
	Alarm relay action same with alarm led	Alarm relay action is the opposite of alarm led
SEAX.2	Alarm delay ON	Alarm delay OFF
	Conditions: When ALTX = 00.01~99.58 When PV entering the alarm range, the timer starts. At this time, the alarm led and relay keep original state, alarm led and relay change state in time up	Conditions: When ALTX = 00.01~99.58 When PV entering the alarm range, the timer starts. At this time, the alarm led and relay change state, alarm led and relay change state again in time up
SEAX.3	ALTX time format (minutes.seconds) Ex : ALT1=33.23 , its time format is 33 minutes and 23 seconds	ALTX time format (hours. minutes) Ex : ALT1=33.23 , its time format is 33 hours and 23 minutes
SEAX.4	Alarm delay ON or delay OFF	Alarm delay ON or delay OFF with flick action
	When ALTX = 00.01~99.58, according to the SETA.2 setting value, the relay and alarm led will continue to operate when an alarm occurs	When ALTX = 00.01~99.58, according to the SETA.2 setting value, the relay and alarm led will flick when an alarm occurs
	SEAX.2=0	SEAX.2=0
		
SEAX.2=1	SEAX.2=1	SEAX.2=1
		

12.3 Alarm Example

Example 1 : Deviation low, the difference between alarm hold action and without alarm hold action, shown in the diagram below



Example 2: Relative relevance between Alarm1 and ALT1 and SEA1




※ X : Don't care

13. Programmable

Description

Programmable function is SV function that is variable to time, as user can set SV value to their needs according to time-based variation curve, which is called program setting

1. There are at most 15 sets of pattern setting
2. Every set of pattern can at most have 10 segments
3. Every segment include 4 settings such as ramp, soak, step and continue
4. Pattern can be randomly linked up, as each pattern of program contains 150 segment, at most.



13.1 Parameter Setting

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
WAIT		Program execution standby temperature 0 : when program execute do not wait for PV temperature Other values : when PV= (target SV-WAIT) program entering next segment	1000	0	0	Level 1	SET4.1
PTN		Program pattern selection 1~15	15	TRIP	1	Level 1	SV.TY = PROG
SEG		Program segment selection 1~10	10	1	1	Level 1	SV.TY = PROG
L1.SV		LOOP1 current segment target SV	USPL	LSPL	0	Level 1	SV.TY = PROG
L2.SV		LOOP2 current segment target SV	USPL	LSPL	0	Level 1	SV.TY=PROG & SET6.4
TIMR		Current segment execute time setting this parameter determines the link between segment and segment or pattern and pattern END(-1) : program end in this segment 00.00 : program step change in this segment 00.01~99.58 : program in this segment execute time COTI(99.59) : program continue execute this segment no end	COTI	END	00.00	Level 1	SV.TY = PROG
MOLH		Current segment output limit	100.0	0.0	100.0	Level 1	SV.TY=PROG & SET6.4


13.1 Parameter Setting

Parameter	Symbol	Content	Range		Default	Level	Hide/Display
			MAX	MIN			
PTMD	P <small>E</small> C <small>D</small> S	Program time format 0 : SEC (minute.second) 1 : MIN (hour.minute) 2 : 50MS (50ms)	50MS	SEC	SEC	Level 5	SETE.1
PVST	P <small>E</small> S <small>E</small> T	Program execute start address 0 : OFF (execute from zero) 1 : ON (execute from current PV)	ON	OFF	ON	Level 5	SETE.1
REPT	P <small>E</small> E <small>R</small> P	Program execute repeat 0 : OFF (disable repeat function) Other : Program execute repeat number of times	9999	OFF	OFF	Level 5	SETE.1
POWF	P <small>E</small> O <small>F</small> F	Program execute power fail protection 0 : OFF (disable power fail protection) 1 : ON (enable power fail protection)	ON	OFF	OFF	Level 5	SETE.1
REMO	P <small>E</small> E <small>R</small> O	Remote control program execute OFF : program execute by key ON : program execute by digital input or communication	ON	OFF	OFF	Level 5	SETD.4

13.2 Key Operation Description

Functions	Keys	Description
Run		Executing program, PRO_LED lamp ON, Upper area shows 3 times "RUN" messages.
Halt		Pause executing program, PRO_LED lamp remains ON, at this moment upper area will display current temperature value and "HALT" message alternately.
Jump	+	Jump to the next segment, and it can skip segment continuously.
		Holding UP key and press SET key 1 time to skip 1 segment, press SET key 2 times to skip 2 segments, so on and so forth.
Reset	+	Stop executing program, PRO_LED lamp OFF, Upper area shows 3 times "REST" messages.
PV/SV monitor		Press the A / M key for 2 seconds jump to the parameter MOUT, then pressing the A / M key for 2 seconds return to PV / SV monitor.

13.3 Program Initial Setting



1. Setting program time format setting

Parameter	LED display	Description	Default	Level
PTMD		Program time format 0 : SEC (minute.second) 1 : MIN (hour.minute) 2 : 50MS (50ms)	SEC	Level 5

This parameter determines the time-base of TIMER during program execution

When PTMD = SEC, TIMR = 33.23, it indicates that the execution time of this segment is 33 minutes and 23 seconds

When PTMD = MIN, TIMR = 33.23, it indicates that the execution time of this segment is 33 hours and 23 minutes

2. Setting program program execute start address

Parameter	LED display	Description	Default	Level
PVST		Program execute start address 0 : OFF (execute from zero) 1 : ON (execute from current PV)	ON	Level 5

When program starts, SV initial value will execute according to PVST set value

(1) PVST =0, PTN=1 PV=50.0 SV_1=100.0 TIMR=1.00(1 hour)

When program starts, SV will start to execute from 0.0, and SV shall reach SV_1 in one hour

(2) PVST =1, PTN=1 PV=50.0 SV_1=100.0 TIMR=1.00(1 hour)

When program starts, SV will start to execute from PV temperature of 50.0, and SV shall reach SV_1 in one hour

3. Setting program execute with repeat function

Parameter	LED display	Description	Default	Level
REPT		Program execute repeat 0 : OFF (disable repeat function) Other : Program execute repeat number of times	OFF	Level 5

When program completes the execution of the final segment, and "END" message is not shown, the program will be executed again.

4. Setting program execute with power failure protection function

Parameter	LED display	Description	Default	Level
POWF		Program execute power fail protection 0 : OFF (disable power fail protection) 1 : ON (enable power fail protection)	OFF	Level 5

Power failure during program execution, if there is power failure protection function set, controller will execute current segment program after booting finish

Assume power failure occurring in the segment_4, ramp temperature from 100°C to 200°C, and power failure occurring at SV=125, the program will execute from 100°C (segment_4), after controller booting finish

5. Setting program execute via communication or digital input

Parameter	LED display	Description	Default	Level
REMO		Remote control program execute OFF : program execute by key ON : program execute by digital input or communication	OFF	Level 5

To control program execution or stop by digital input, please refer to the Chapter 12.6, this function only available in program type controller with digital input option

To control program execution or stop by communication, please refer to the definition of parameter PKE1 in the communication operation manual, this function only available in program type controller with communication option

6. Setting program execute with wait function

Parameter	LED display	Description	Default	Level
WAIT		Program execution standby temperature 0 : when program execute do not wait for PV Other values : when PV= (SV-WAIT), program entering next segment	0	Level 1

When program executes, if WAIT=0.0, and SV reaches set temperature, whether PV reaches target temperature or not, the controller will enter the next segment

When program executes, if WAIT value is not 0.0, and SV reaches set temperature, as PV has not reached target temperature, controller will wait for PV temperature to reach (target SV-WAIT)

(1) WAIT = 0.0 without wait function set

Assume the set temperature of current segment is 100.0°C, and as SV reaches the set temperature of this segment, the controller will enter to the next segment


(2) WAIT = 5.0 with wait function set

Assume the set temperature of current segment is 100.0°C, and as SV reaches the set temperature of this segment, PV temperature needs to reach 100.0-5.0 (SV-WAIT)=95.0 then entering to the next segment


13.4 Create Program

There are 15 sets PTN to choose and each PTN have 10 segments for setting

Program structure diagram



Program edit flow-chat



1. Choose program pattern number

Parameter	LED display	Description	Default	Level
PTN	8PEN	Program pattern selection 1~15	1	Level 1

2. Choose program segment number

Parameter	LED display	Description	Default	Level
SEG	8SEG	Program segment selection 1~10	1	Level 1

3. Setting LOOP1 current segment target SV

Parameter	LED display	Description	Default	Level
L1.SV	11158	LOOP1 current segment target SV	100	Level 1

4. Setting LOOP2 current segment target SV

Parameter	LED display	Description	Default	Level
L2.SV	12258	LOOP2 current segment target SV	0	Level 1

5. Setting current segment execute time

Parameter	LED display	Description	Default	Level
TIMR	8000	Current segment execute time setting this parameter determines the link between segment and segment or pattern and pattern END(-1) : program end in this segment 00.00 : program step change in this segment 00.01~99.58 : program in this segment execute time COTI(99.59) : program continue execute this segment no end	00.10	Level 1

TIMR setting explain :

In segment_5(SEG_5) setting TIMR=END

→ When the program finishes segment_4(SEG_4), program end and display "END" message, can't jump to next segment.

In segment_5(SEG_5) setting TIMR=00.00

→ When the program finishes segment_4(SEG_4), jump to next segment SV change suddenly


In segment_5(SEG_5) setting TIMR=10.00

→ When the program finishes segment_4(SEG_4), jump to next segment and executing TIMR setting value

In segment_5(SEG_5) setting TIMR=COTI

→ When the program finishes segment_4(SEG_4), jump to next segment and executing continue can't jump to next segment or end state


13.5 Program Execution Flow



13.6 Program Setting Example

In pattern_1 edit program ramp, soak, step and continue

Temperature



Initial setting



PTMD = SEC	PVST = OFF	REPT = OFF	POWF = ON	WAIT = 0.5
------------	------------	------------	-----------	------------

Program edit



Segment_1	Segment_2	Segment_3	Segment_4	Segment_5	Segment_6	Segment_7
PTN = 1						
SV_1 = 200	SV_2 = 200	SV_3 = 250	SV_4 = 250	SV_5 = 80	SV_6 = 80	SV_7 = 0
TM_1 = 60.00	TM_2 = 30.00	TM_3 = 0.00	TM_4 = 30.00	TM_5 = 40.00	TM_6 = 45.00	TM_7 = END
MOLH = 100.0	MOLH = 0.0					

14. Modification Of Output Module



14.1 Relay Control (1a)

Side view	Bottom view	Software Setting
		Parameter set as "CYT1 =10"

14.2 Relay Control (1c)



Side view	Bottom view	Software Setting
		Parameter set as "CYT1 =10"

14.3 SSR Control

Top view	Bottom view	Software Setting
		Parameter set as "CYT1 =1"


14.4 Linear Control

When modifying mA current module, output signal needs to be calibrated, and for detailed calibration procedure, please refer to [Chap. 14.5 Output Calibration Procedure Diagram](#)

Top view	Bottom view	Software Setting
		Parameter set as "CYT1 =0"


14.5 Output Calibration Procedure Diagram

Output1 Signal (4mA~20mA) calibration flowchart




14.6 Output Calibration Steps


1. Display MOCL & MOCH :



2. Adjust MOCL low-point calibration value :





3. Adjust MOCH high-point calibration value





15. Modification Of Input Signal

15.1 Input Modify To Thermocouple

Jumper Position	Software Setting
Plug 2 pcs of Jumper into the middle slot as shown  	Parameter set as "INPT=K1~L"


15.2 Input Modify To RTD

Jumper Position	Software Setting
Plug 2 pcs of Jumper into the left slot as shown  	Parameter set "INPT=PT1~PT3"

15.3 Input Modify To Linear (4~20mA)

Jumper Position		Software Setting
Plug 2 pcs of Jumper into the right slot as shown		
		Parameter set as "INPT=AN4"

Linear analog signal (4~20mA) calibration flowchart




Notes

- When TC/RTD input is modified to linear analog signal (4~20mA), input signal needs to be calibrated.
- When linear analog signal (4~20mA) input is modified to TC/RTD, please memory current AN.LO and AN.HI value and recover AN.LO and AN.HI to default value (AN.LO = 0, AN.HI = 5FFF)


15.4 Steps For Input Calibration

1. Display AN.LO, AN.HI, DP :




※ X is the default value which does not require modification

2. Adjustment of AN.LO calibration values



※ AN.LO calibration value of each controller is different from the other

3. Adjustment of AN.HI calibration values



※ AN.HI calibration value of each controller is different from the other


16. Zero / Phase Control

16.1 1φ Zero Cross Control (SCR module)

OUT1 : 1φ SCR zero cross control

Parameter setting : OUT.TY= 1SCR, CYT1= 1

Wiring Setup:




16.2 1φ Zero Cross Control (TRIAC module)

OUT1 : 1φ SCR zero cross control

Parameter setting : OUT.TY= 1SCR, CYT1= 1

Wiring Setup:




16.3 3φ Zero Cross Control (SCR module)

OUT1 : 3φ SCR zero cross control

Parameter setting : OU.TY= 1SCR, CYT1= 1

Wiring Setup :




16.4 3φ Zero Cross Control (TRIAC module)

OUT1 : 3φ SCR zero cross control

Parameter setting : OU.TY= 1SCR, CYT1= 1

Wiring Setup :




16.5 1φ Phase Angle Control (SCR module)

OUT1 : 1φ SCR phase angle control

Parameter setting : OU.TY= 1SCR, CYT1= 0

Wiring Setup :




16.6 1φ Phase Angle Control (TRIAC module)

OUT1 : 1φ SCR phase angle control

Parameter setting : OU.TY= 1SCR, CYT1= 0

Wiring Setup :



17. Error Message

If controller exhibits any of the following issues, please proceed with the following procedures

Symbol	Error	Solution
	INIE: Input1 Error	Check whether input loop is opened or wiring is incorrect.
	UUUU: PV is above USPL	Check whether the input value is correct or not.
	NNNN: PV is below LSPL	Check whether the input value is correct or not.

If any of the indication in the table below appear, the controller need to be repaired do not try to repair the controller by yourself, order a new one or contact us to repair.

Symbol	Error	Solution
	ADCF: A/D convert failed	Please send for repair.
	CJER: Cold junction compensation failed	Please send for repair.
	RAMF: EEPROM failed	Please send for repair.

18. WT Communication Register Address Table

LOOP1 Parameter address

Parameter	Register Address		R / W
	Hex	Dec	
PV	0x00	0	R
SV	0x01	1	R / W
LOOP	0x02	2	R / W
R_S	0x03	3	R / W
HBCU	0x04	4	R
HBSV	0x05	5	R / W
HTBM	0x06	6	R / W
AL1H	0x07	7	R / W
AL1L	0x08	8	R / W
AL2H	0x09	9	R / W
AL2L	0x0A	10	R / W
AL3H	0x0B	11	R / W
AL3L	0x0C	12	R / W
SV1	0x0D	13	R / W
SV2	0x0E	14	R / W
SV3	0x0F	15	R / W
SV4	0x10	16	R / W
TIM	0x11	17	R / W
CNT	0x12	18	R / W
CUTM	0x13	19	R / W
ONTM	0x14	20	R / W
OFTM	0x15	21	R / W
A_M	0x16	22	R / W
MOUT	0x17	23	R / W
AT	0x18	24	R / W
RATE	0x19	25	R / W
RAMP	0x1A	26	R / W
SOAK	0x1B	27	R / W
WAIT	0x1C	28	R / W
DTM1	0x1D	29	R / W
DTM2	0x1E	30	R / W
DTM3	0x1F	31	R / W
DTM4	0x20	32	R / W
DT.ST	0x21	33	R / W
PTN	0x22	34	R / W
SEG	0x23	35	R / W
L1SV	0x24	36	R / W
L2SV	0x25	37	R / W
TIMR	0x26	38	R / W
DOUT	0x27	39	R / W
P1	0x28	40	R / W
M_LP	0x29	41	R / W
I1	0x2A	42	R / W
M_LI	0x2B	43	R / W
D1	0x2C	44	R / W
M_LD	0x2D	45	R / W
HYS1	0x2E	46	R / W
CYT1	0x2F	47	R / W

Parameter	Register Address		R / W
	Hex	Dec	
MOLH	0x30	48	R / W
MOLL	0x31	49	R / W
P2	0x32	50	R / W
S_LP	0x33	51	R / W
I2	0x34	52	R / W
S_LI	0x35	53	R / W
D2	0x36	54	R / W
S_LD	0x37	55	R / W
HYS2	0x38	56	R / W
CYT2	0x39	57	R / W
SOLH	0x3A	58	R / W
SOLL	0x3B	59	R / W
MGAP	0x3C	60	R / W
SGAP	0x3D	61	R / W
COUT	0x3E	62	R
AT.VL	0x3F	63	R / W
SS.PO	0x40	64	R / W
OPSF	0x41	65	R / W
RC.TO	0x42	66	R / W
LOCK	0x43	67	R / W
INPT	0x44	68	R / W
AN.LO	0x45	69	R / W
AN.HI	0x46	70	R / W
DP	0x47	71	R / W
HI.RA	0x48	72	R / W
LO.RA	0x49	73	R / W
USPL	0x4A	74	R / W
LSPL	0x4B	75	R / W
ALD1	0x4C	76	R / W
ALT1	0x4D	77	R / W
HYA1	0x4E	78	R / W
SEA1	0x4F	79	R / W
ALD2	0x50	80	R / W
ALT2	0x51	81	R / W
HYA2	0x52	82	R / W
SEA2	0x53	83	R / W
ALD3	0x54	84	R / W
ALT3	0x55	85	R / W
HYA3	0x56	86	R / W
SEA3	0x57	87	R / W
MOCL	0x58	88	R / W
MOCH	0x59	89	R / W
SOCL	0x5A	90	R / W
SOCH	0x5B	91	R / W
MV.SF	0x5C	92	R / W
RC.TI	0x5D	93	R / W
UNIT	0x5E	94	R / W
OUTM	0x5F	95	R / W

18. WT Communication Register Address Table

LOOP1 Parameter address

19. FY Communication Register Address Table

Parameter	Register Address		R / W
	Hex	Dec	
SV	0x00	0	R / W
OUTL	0x01	1	R / W
AT	0x02	2	R / W
AL1			
SOAK	0x03	3	R / W
HBAC			
AL2			
SOAK	0x04	4	R / W
HBAC			
AL3			
SOAK			
RAMP	0x05	5	R / W
RATE			
PTN	0x06	6	R / W
SEG	0x07	7	R
TIMR	0x08	8	R
SV_1	0x09	9	R / W
TM_1	0x0A	10	R / W
OUT1	0x0B	11	R / W
SV_2	0x0C	12	R / W
TM_2	0x0D	13	R / W
OUT2	0x0E	14	R / W
SV_3	0x0F	15	R / W
TM_3	0x10	16	R / W
OUT3	0x11	17	R / W
SV_4	0x12	18	R / W
TM_4	0x13	19	R / W
OUT4	0x14	20	R / W
SV_5	0x15	21	R / W
TM_5	0x16	22	R / W
OUT5	0x17	23	R / W
SV_6	0x18	24	R / W
TM_6	0x19	25	R / W
OUT6	0x1A	26	R / W
SV_7	0x1B	27	R / W
TM_7	0x1C	28	R / W
OUT7	0x1D	29	R / W
SV_8	0x1E	30	R / W
TM_8	0x1F	31	R / W
OUT8	0x20	32	R / W
SV_12	0x21	33	R / W
TM_12	0x22	34	R / W
OUT12	0x23	35	R / W
SV_22	0x24	36	R / W
TM_22	0x25	37	R / W
OUT22	0x26	38	R / W
SV_32	0x27	39	R / W
TM_32	0x28	40	R / W
OUT32	0x29	41	R / W
SV_42	0x2A	42	R / W
TM_42	0x2B	43	R / W
OUT42	0x2C	44	R / W
SV_52	0x2D	45	R / W
TM_52	0x2E	46	R / W
OUT52	0x2F	47	R / W
SV_62	0x30	48	R / W
TM_62	0x31	49	R / W
OUT62	0x32	50	R / W
SV_72	0x33	51	R / W
TM_72	0x34	52	R / W
OUT72	0x35	53	R / W
SV_82	0x36	54	R / W
TM_82	0x37	55	R / W
OUT82	0x38	56	R / W
P1	0x39	57	R / W
I1	0x3A	58	R / W
D1	0x3B	59	R / W
AT.VL	0x3D	61	R / W
CYT1	0x3E	62	R / W
HYS1	0x3F	63	R / W

Parameter	Register Address		R / W
	Hex	Dec	
P2	0x40	64	R / W
I2	0x41	65	R / W
D2	0x42	66	R / W
CYT2	0x43	67	R / W
HYS2	0x44	68	R / W
GAP1	0x45	69	R / W
GAP2	0x46	70	R / W
LCK	0x47	71	R / W
INP1	0x48	72	R / W
ANL1	0x49	73	R / W
ANH1	0x4A	74	R / W
DP	0x4B	75	R / W
LSPL	0x4C	76	R / W
USPL	0x4D	77	R / W
ANL2	0x4E	78	R / W
ANH2	0x4F	79	R / W
ALD1	0x50	80	R / W
ALT1	0x51	81	R / W
ALD2	0x52	82	R / W
ALT2	0x53	83	R / W
ALD3	0x54	84	R / W
ALT3	0x55	85	R / W
HYSA	0x56	86	R / W
CLO1	0x57	87	R / W
CHO1	0x58	88	R / W
CLO2	0x59	89	R / W
CHO2	0x5A	90	R / W
CLO3	0x5B	91	R / W
CHO3	0x5C	92	R / W
RHTC			
RUCY	0x5D	93	R / W
RHPO			
WAIT	0x5E	94	R / W
SETA	0x5F	95	R / W
PSL	0x60	96	R
BITS	0x61	97	R
IDNO	0x62	98	R
BAUD	0x63	99	R
SVOS	0x64	100	R / W
PVOS	0x65	101	R / W
UNIT	0x66	102	R / W
PVFT	0x67	103	R / W
PV2	0x68	104	R / W
OUD	0x69	105	R / W
OPAD	0x6A	106	R / W
HZ	0x6B	107	R / W
SET1	0x6C	108	R / W
SET2	0x6D	109	R / W
SET3	0x6E	110	R / W
SET4	0x6F	111	R / W
SET5	0x70	112	R / W
SET6	0x71	113	R / W
SET7	0x72	114	R / W
SET8	0x73	115	R / W
SET9	0x74	116	R / W
SET0	0x75	117	R / W
INP2	0x76	118	R / W
OUTY	0x77	119	R / W
OUT%	0x87	135	R
OBIT	0x88	136	R
CV	0x89	137	R
PV	0x8A	138	R

20. Program Design Table

OUTM(control action)	<input type="checkbox"/> HEAT
	<input type="checkbox"/> COOL
WAIT (SET4.1)	
REPT(SETE.1)	<input type="checkbox"/> 0 : OFF (disable repeat function) <input type="checkbox"/> Other : repeat number of times
POWF (SETE.1)	<input type="checkbox"/> 0 : OFF (disable power fail protection) <input type="checkbox"/> 1 : ON (enable power fail protection)
PVST (SETE.1)	<input type="checkbox"/> 0 : OFF (execute from zero) <input type="checkbox"/> 1 : ON (execute from current PV)
PTMD (SETE.1)	<input type="checkbox"/> 0 : SEC (minute. second) <input type="checkbox"/> 1 : MIN (hour.minute) <input type="checkbox"/> 2 : 50MS (50ms)

SEG	Parameter	PTN=1	PTN=2	PTN=3	PTN=4	PTN=5	PTN=6	PTN=7	PTN=8
1	L1.SV								
	TIMR								
	MOLH								
2	L1.SV								
	TIMR								
	MOLH								
3	L1.SV								
	TIMR								
	MOLH								
4	L1.SV								
	TIMR								
	MOLH								
5	L1.SV								
	TIMR								
	MOLH								
6	L1.SV								
	TIMR								
	MOLH								
7	L1.SV								
	TIMR								
	MOLH								
8	L1.SV								
	TIMR								
	MOLH								
9	L1.SV								
	TIMR								
	MOLH								
10	L1.SV								
	TIMR								
	MOLH								

SEG	Parameter	PTN=9	PTN=10	PTN=11	PTN=12	PTN=13	PTN=14	PTN=15
1	L1.SV							
	TIMR							
	MOLH							
2	L1.SV							
	TIMR							
	MOLH							
3	L1.SV							
	TIMR							
	MOLH							
4	L1.SV							
	TIMR							
	MOLH							
5	L1.SV							
	TIMR							
	MOLH							
6	L1.SV							
	TIMR							
	MOLH							
7	L1.SV							
	TIMR							
	MOLH							
8	L1.SV							
	TIMR							
	MOLH							
9	L1.SV							
	TIMR							
	MOLH							
10	L1.SV							
	TIMR							
	MOLH							

21. Glossary Of Characters Used In This Manual

LED Display	0	1	2	3	4	5	6	7	8	9
Characters	0	1	2	3	4	5	6	7	8	9
LED Display	A	B	C	D	E	F	G	H	I	J
Characters	K	L	M	N	O	P	Q	R	S	T
LED Display	U	V	W	X	Y	Z	°C	°F		
Characters	U	V	W	X	Y	Z	°C	°F		

22. WT Parameter Abbreviation Descriptions

PV	Process value
SV	Set value
LOOP	Loop
R_S	Run_Stop
HBCU	Heater Break Current
HBSV	Heater Break SV
HTBM	Heater Break timer
AL1H	Alarm 1 high value
AL1L	Alarm 1 low value
AL2H	Alarm 2 high value
AL2L	Alarm 2 low value
AL3H	Alarm 3 high value
AL3L	Alarm 3 low value
SV1~SV4	Set value 1~4
TIM	Timer
CNT	Counter
CUTM	Current time
ONTM	ON time
OFTM	OFF time
A_M	Auto_manual
MOUT	Manual out
AT	Control mode
RATE	Rate
RAMP	Ramp
SOAK	Soak
WAIT	Program action waiting for temperature
DTM1~DTM4	Do timer 1~4
DT.ST	Do timer set
PTN	Pattern
SEG	Segment
L1SV	Loop 1 SV
L2SV	Loop 2 SV
TIMR	Use for program
DOUT	Digit out
P1	Main proportional band
M_LP	Main low proportional band
I1	Main integral
M_LI	Main low integral
D1	Main differential
M_LD	Main low differential
HYS1	Main hysteresis
CYT1	Main cycle time
MOLH	Main output limit high
MOLL	Main output limit low
P2	Sub proportional band
S_LP	Sub low proportional band
I2	Sub integral
S_LI	Sub low integral
D2	Sub differential
S_LD	Sub low differential
HYS2	Sub hysteresis
CYT2	Sub cycle time
SOLH	Sub output limit high
SOLL	Sub output limit low
MGAP	Main gap
SGAP	Sub gap
COUT	Current output
AT.VL	Autotune offset value
SS.PO	Steady state power
OPSF	Output special function
RC.TO	Low pass filter RC const.time for output
LOCK	Lock
INPT	Input type
AN.LO	Analog input calibrate low
AN.HI	Analog input calibrate high
DP	Point
HI.RA	High range
LO.RA	Low range
USPL	Upper set point limit
LSPL	Lower set point limit
ALD1	Alarm 1 mode
ALT1	Alarm 1 timer
HYA1	Hysteresis for alarm 1
SEA1	Special function for alarm 1
ALD2	Alarm 2 mode

22. WT Parameter Abbreviation Descriptions

ALT2	Alarm 2 timer
HYA2	Hysteresis for alarm 2
SEA2	Special function for alarm 2
ALD3	Alarm 3 mode
ALT3	Alarm 3 timer
HYA3	Hysteresis for alarm 3
SEA3	Special function for alarm 3
MOCL	Main output calibrate low
MOCH	Main output calibrate high
SOCL	Sub output calibrate low
SOCH	Sub output calibrate high
MV.SF	mV special function for input
RC.TI	Low pass filter RC const.time for input
UNIT	Unit
OUTM	Output mode
SV.OS	SV offset
PV.OS	PV offset
PV.OH	PV offset high
MLNB	Manual linearize number
COMP	Compare for manual linearize
OFFS	Offset for manual linearize
SV.TY	SV type
OU.TY	Output type
PMAC	Process RC const.Gain
FKSL	function key select
BIAS	---
TP_K	---
TMSL	Timer mode select
MVRT	Motor value run time
HYSM	Hysteresis for motor value
RH.TC	(Relative humidity) temperature of except wet
RH.PO	(Relative humidity) power of except wet
RH.TM	(Relative humidity) time of except wet
PR.SV	Pretune SV
AT.SV	Autotune SV
SET1	---
SET2	---
SET3	---
SET4	---
SET5	---
SET6	---
SET7	---
SET8	---
SET9	---
SETA	---
SETB	---
SETC	---
SETD	---
SETE	---
SETF	---
HZ	HZ
PRTO	Protocol
FOMA	Data format
IDNO	ID number
BAUD	Baud rate
RPDT	Response Delay time
AOEN	Analog output enable
AOSL	Analog output signal select
AO.LO	Analog output scale low
AO.HI	Analog output scale high
AOCL	Analog output calibrate low
AOCH	Analog output calibrate high
CTRTR	Current transformer ratio
D1SL	Digital input 1 select
D2SL	Digital input 2 select
REMO	Program remote control
CJSL	Cold junction select
CJMN	Manual set cold junction
CJTC	Cold junction temperature
W_MD	Write mode for uart
RMAP	Ram mapping
OPSL	Output select
POTM	Power ON delay time

22. WT Parameter Abbreviation Descriptions

PTMD	Program time mode
PVST	PV start
REPT	Repeat
POWF	Power failure

www.thietbicodien.com.vn

www.thietbicodien.com.vn

www.thietbicodien.com.vn

www.thietbicodien.com.vn

www.thietbicodien.com.vn